

User Instruction

Wi-Fi Smart LED Strip Light




V1.1

Email: Servicevip1@outlook.com


FCC ID:2A7WU-D32128A

Product Installation


Step1: Connect LED Controller with LED Light Strip.



Step2: Connect the LED Controller with power supply.



Step3: Plug in the power supply.




WARNING

- ⚠ Do not connect the power supply to wall plug before installation.
- ⚠ Spread out the lights strip before using. Don't Light it Up in Reel.
- ⚠ Test the lights before installing.

IR remote control

1. Brightness up / Speed up
2. Brightness down / Speed down
3. ON.
(Press and hold ON button for 3 seconds can reset the light.)
4. OFF
5. Static colors.
6. Dynamic light effects:
JUMP3/JUMP7/FADE3/FADE7
7. Music Sync.



Install APP and Log in

Install DayBetter APP on your phone

You can set up your account password on APP setting page.

Then you can use password to log in and to link Alexa.



Set Account Password

Reset Device

One device is configed online, it must be reset before it can be configed by another account.

Two methods to reset device:


Method 1: Power on the device, then hold the 'ON' button on remote until the lights start flashing.



Add Device and Config online

Click "Go to search" to search nearby devices.

Click "Add", then the device will be added to your device list.



Install APP and Log in

Turn on phone Wi-Fi and Bluetooth

Go to connect device to WiFi on device info page.



Install APP and Log in

Install DayBetter APP on your phone

You can set up your account password on APP setting page.

Then you can use password to log in and to link Alexa.



Set Account Password

Reset Device

One device is configed online, it must be reset before it can be configed by another account.

Two methods to reset device:


Method 1: Power on the device, then hold the 'ON' button on remote until the lights start flashing.



Add Device and Config online

Click "Go to search" to search nearby devices.

Click "Add", then the device will be added to your device list.





Install APP and Log in

Turn on phone Wi-Fi and Bluetooth


Go to connect device to WiFi on device info page.



Wait for connecting. After the connection is complete, click "OK".




Device detail information.



7

Link Alexa or Google Home

Method 1: Bind Alexa on DayBetter APP(Recommended)
(1) Go to APP setting page and click Alexa tab to call LINK page.
(2) Then just click LINK on the link page.
(3) Wait a second. Done. You can find device on Alexa APP.



Note: Ensure the device is WiFi-connected and Alexa APP already logged in, before you link to Alexa.


8

Method 2: Bind DayBetter on Alexa APP(NOT recommended)

Search and enable 'DayBetter' skill on Alexa APP.
Please scan the QR code for more help.



Please scan the QR code for how to link Google Home.



9

c) All lights don't work.

- Check power on.
- Press ON and press 'brightness up' multi times in one second.
- Connect AP and turn on light and turn up brightness.
- Reinstall applets.
- Check the light is on.
- Kill APP, turn off bluetooth and turn on bluetooth again, then start APP to add device again.
- Ensure phone within 4ft from product when connecting.
- Your phone may be incompatible with the API, try another phone.

Attention

- Use the product with provided adapter and control box only.
- Do NOT extend more steps to avoid overload which is unsafe.
- Do NOT bend strip, otherwise beads and parts may damage.
- Please turn off the power and unplug the adapter when the strip light will not be used for a long time.

After-sale & Warranty

Please contact us if you get a defective product. We will reply to you within 24 hours.

All products come with limited warranty of 12 months from the date of purchase. We will do our best to help you solve any problems you might have about our products until you are satisfied. We appreciate your support and cooperation.


Servicevip@outlook.com

10

Main User Interface

Trouble Shooting

1.Device status information.



a) APP can not find the device.

- Make sure the phone bluetooth is on.
- Allow the permissions of APP. APP needs them to connect.
- Reinstall applets.
- Check the light is on.
- Kill APP, turn off bluetooth and turn on bluetooth again, then start APP to add device again.

e) Some lights keep off or fail working.

- Contact our support team.

Attention

- Use the product with provided adapter and control box only.
- Do NOT extend more steps to avoid overload which is unsafe.
- Do NOT bend strip, otherwise beads and parts may damage.
- Please turn off the power and unplug the adapter when the strip light will not be used for a long time.

After-sale & Warranty

Please contact us if you get a defective product. We will reply to you within 24 hours.

All products come with limited warranty of 12 months from the date of purchase. We will do our best to help you solve any problems you might have about our products until you are satisfied. We appreciate your support and cooperation.

Servicevip@outlook.com

11

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

12

13