

年Y月M日D	更正记事 ECN RECORD	版本REV
2025/05/16	首版发行	A




Wireless HDMI Transmitter and Receiver

User Manual | VWS-H70

Specifications

Model: ADK
Interface: HDMI/USB-C
Electroplating Process: Nickel-Plated
Material: ABS
Resolution: 1080P@60Hz
Power Supply: 5V~2A
Wireless Frequency: 5GHz
Effective Range: 50 m (Max)

Product Overview




Transmitter-TX
① HDMI Port
② Indicator Light
③ USB-C Power Port
④ Function Button

Receiver-RX
① HDMI Port
② Indicator Light
③ USB-C Power Port
④ Function Button

Screen Mirroring


Plug and Play



1. Connect the HDMI port (receiver) to the display device like a monitor or TV.
2. Plug the USB-C power port (receiver) into a charger or USB-C power port (5V~2A) and turn on the receiver.
3. Set the display device to the correct HDMI input. The startup screen will appear when the receiver is ready.
4. Connect the transmitter to a device with an HDMI output. Wait for the indicator light to flash to complete the connection.

Note: Please ensure the upstream device has sufficient power. If not, connect the transmitter to an adapter or USB-C power port (5V~2A).

What's in the Box



Wireless HDMI Transmitter and Receiver *1
USB-C Cable(1m) *2
User Manual *1

For more interesting information and events, please follow us on social media platforms:




Facebook LinkedIn Instagram

For warranty service or support, please contact Vention team:
Website: www.ventiontech.com Email: vention@ventiontech.com

TX-RX Pairing

The two devices are pre-paired during manufacturing. If pairing fails due to improper handling or other issues, follow these steps to reset and re-pair them:



Transmitter Indicator Light Status:
- Slow Flashing: Not Connected
- Fast Flashing: Pairing
- Steady Light: Connected
- Double Flashing: Transmitter Not Connected
- Triple Flashing: Software Error
- Breathing Light: Screen Casting Paused

1. Press and hold the Receiver (RX) Function Button for 3s or more until "Connecting..." appears on the screen, indicating Pairing Mode.
2. Press and hold the Transmitter (TX) Function Button for 5s or more. The indicator will flash quickly while pairing. When it stays on steadily, pairing is complete.

FAQs



Q1: How do I reset to default settings?
A1: If the product malfunctions, press and hold the Receiver (RX) Function Button for 10s. The screen will go black and restart, resetting to default settings.

Q2: How do I enter Privacy Mode?
A2: Simply press the Transmitter (TX) Function Button to disconnect or reconnect.

Q3: Can devices without a HDMI port be used?
A3: Yes, but please use a full-function HDMI adapter with the device.

FCC ID: 2A7Z4-ADK

成品尺寸: 70x90mm
材质: 80g哑粉纸 3页 风琴折 双面印刷
蓝色印刷: C100 M:0 Y:0 K:0 参考: Pantone Process Cyan C

宁波福茂通讯科技有限公司 NINGBO FULMAN COMMUNICATION TECHNOLOGY CO.,LTD			
品名 PART NAME	ADK系列 无线投屏收发器说明书	型号 PART MODEL	VWS-H70
设计 DESIGNER	Muzi	单位 UNIT	mm
校对 CHECK		版本 REV	A2
核准 APPR.		页数 PAGE	1/1
		更新 UPDATE	2025/05/16