

说明书80g铜版纸双面单色印刷

75.00 mm

OWS 无线耳机
LIGHT AND COMFORTABLE
Model: KLV-62

使用说明书

结构示意图

1.Type-C充电接口 2.电量指示灯 3.幻彩渲染灯
4.充电仓充电触点 5.麦克风 6.触摸区域
7.指示灯 8.出音孔 9.耳机充电触点

功能介绍

开机
耳机从充电仓中取出/耳机关机状态下长按2秒手动开机，白灯呼吸，耳机提示音Power on，此时耳机进入回连状态，如附近有曾经配对连接过的设备，将自动回连至该设备，如无设备，等待约8秒主耳自动进入设备配对状态，提示音Pairing，主耳白灯呼吸进入设备配对模式无线配对
打开手机并开启蓝牙，刷新蓝牙列表，找到“KLV-62”设备，点击该设备进行配对，连接成功后耳机提示：Connected，主副耳白灯长亮，手机上显示耳机已连接。

关机
耳机放入充电仓自动关机充电/开机状态下长按5秒手动关机(手动关机主副耳会同步关机)，橙灯长亮1秒，耳机提示Power Off，如只需使用其中一只耳机，只需要将另一只耳机放回充电盒，5分钟无连接设备或者电池电压低于3.2V时，耳机将自动关机。

恢复出厂设置
在不连接无线的情况下，连续触摸5次，白橙灯快速闪烁，耳机恢复出厂设置，等待约10s后按照无线配对步骤重新连接设备即可。

指示灯状态

耳机

- 1.开机：白色LED灯呼吸
- 2.关机：橙色LED灯长亮1秒
- 3.耳机互配成功：主耳白灯呼吸，副耳灭灯
- 4.与设备连接成功：主副耳无操作时白灯长亮，有操作时灭灯
- 5.充电时：橙灯长亮

充电仓

- 1.充电仓充电：插充电线后，充电仓冰蓝灯1.2.3逐级闪烁，幻彩灯长亮
(冰蓝灯1为0%-30%电量，2为30%-60%电量，3为60%-100%电量)
- 2.充电仓满电（插线）：冰蓝灯长亮，幻彩灯呼吸
- 3.充电仓给耳机充电（无外接充电器）：冰蓝灯闪烁，幻彩灯呼吸15秒幻彩灯

1.耳机出仓与进仓时唤醒并长亮15秒后灭灯，充电仓低电时不会唤醒
2.充电仓插线充电/充满时长亮呼吸
注：耳机在仓内充满电后出仓不会唤醒幻彩灯

触控功能 ● 单击 □ 长按 / 无操作

功能	左耳(L)	右耳(R)
功能	1	2
上一曲	3	4
下一曲	5	6
播放/暂停	7	8
接听	9	10
挂断	11	12
拒接	13	14
清除配对	15	16
语音助手	17	18

产品参数

- 无线版本：V5.4
- 工作温度：-5°C to 45°C
- 工作电压：3.0V-4.2V
- 电池容量：耳机[55mAh]，充电仓[240mAh]
- 充电时间：约90分钟
- 充电盒可提供充电次数：约1.5-2次
- 音乐时间：约8小时（中等音量）
- 通话时间：约7小时
- 连接距离：10-15米
- 音频解码：AAC,SBC
- 频率(Hz)：20Hz-20KHz
- 输入电流：5V/0.5A
- 输出电流：5V/40mAh（单个）

注意事项

- 1.使用时请防止耳机掉落、撞击、剧烈震动、扭曲、刮擦、投入水火当中，耳机内含电池，不得暴露在日照、火烤或类似过热环境中。
- 2.耳机尽量远离磁体附近，不要在极冷极热、多尘和潮湿的环境中使用本机。
- 3.为避免损伤听力，请将音量保持在适度水平，避免长时间高音量听音乐，这可能对听力造成永久性伤害或失聪；请在驾驶、骑自行车、过马路等需要您的注意力集中的情况下谨慎使用。
- 4.产品的性能和功能而发生的变化，将另行通知；请勿擅自拆卸本机，以免发生危险。
- 5.充电完成后，请把充电线从机身拔出，避免让产品长时间处于充电状态。充电器输出电压和电流不大于5V/1.5A，如因充电器的输出电压和电流超出指定，这会对本产品造成严重损害，产品保修将同时失效。

OWS WIRELESS EARPHONES
LIGHT AND COMFORTABLE
Model: KLV-62

User Manual

Charging Case and Earphone Structure Diagram

1.Type-C charging interface 2. Battery indicator light 3. Colorful rendering light
4. Charging compartment charging contacts 5. Microphone 6. Touch area
7. Indicator light 8. Sound hole 9. Earphone charging contact

Function Introduction

Power On
Remove the earphones from the charging case or, if the earphones are turned off, press and hold for 2 seconds to manually power them on. The white light will blink, and the earphones will emit a "Power on" prompt, indicating that the earphones are now entering the reconnection state. If there are any devices that have previously been paired and are nearby, the earphones will automatically reconnect to those devices. If no devices are nearby, the earphones will automatically enter the device pairing mode after 8 seconds. The main earpiece will automatically enter the device pairing mode with a "Pairing" prompt, and the white light on the main earpiece will blink, indicating it has entered the device pairing mode.

Wireless Pairing
Turn on your phone and enable wireless, then refresh the wireless device list to find the KLV-62 device, tap on the device to pair with it. Once connected successfully, the earphones will emit a "Connected" prompt, and the main and secondary earpiece's white lights will stay on steadily. Your phone will display that the earphones have connected.

Power Off
Put the earphones into the charging case to power off and charge automatically. / To power off manually while in the on state, press and hold for 5 seconds (manual power off will sync both the main and secondary earpieces), the orange light will stay on for 1 second, and the earphones will emit a "Power Off" prompt.

Factory Reset
If pairing is disrupted and needs to be restored, touch either earbud 5 times continuously without a wireless connection, the white and orange LED indicators will flash rapidly. The earbuds will reset to factory settings. Wait about 10 seconds and then reconnect the device following the wireless pairing steps.

Indicator Light Status

1. Power on: White LED light for breathing.
2. Shutdown: The orange LED light stays on for 1 second.
3. Successful headphone pairing: main ear white light breathing, secondary ear light off.
4. Successfully connected to the device: The white light stays on when there is no operation on the primary and secondary ears, and turns off when there is operation.
5. When charging, the orange light stays on for a long time.

Charging compartment

- 1. Charging compartment: After plugging in the charging cable, the ice blue light in the charging compartment flashes step by step, and the colorful light stays on for breathing. (Ice Blue Lamp 1 has 0% - 30% battery life, 2 has 30% - 60% battery life, and 3 has 60% - 100% battery life.)
- 2. Charging case is charged (plug in): Ice blue light stays on, phantom light breathes.
- 3. Charging case for earphones (without external charger): Ice blue light flashes, phantom light breathes for 15 seconds.

Colored lights

- 1. Wake up and keep on the earphones for 15 seconds before turning off the lights when the earbuds are out and in, and do not wake up when the charging compartment is low.
- 2. Charging compartment plug-in charging/full charge duration, bright breathing.

Note: The earphones will not wake up the colored lights when they are fully charged in the compartment and taken out of the compartment.

Touch Control Features ● Single Tap □ Long Press / No Operation

Function	Left Earphone(L)	Right Earphone(R)
Function	1	2
Previous Track	3	4
Next Track	5	6
Play/Pause	7	8
Answer Call	9	10
Hang Up	11	12
Reject Call	13	14
Clear Pairing	15	16
Voice Assistant	17	18

Product Description

- Version: V5.4
- Operating Temperature: -5°C to 45°C
- Working Voltage: 3.0V-4.2V
- Earphone Battery Capacity: 55mAh
- Earphone Charging Time: Approximately 1.5 hours
- Charging Case Charging Time: Approximately 4 hours
- Charging Case Battery Capacity: 240mAh
- Charging Cycles: Approximately 1.5-2 times
- Music Playing Time: Approximately 8 hours
- Talk time: approximately 7 hours
- Connection Range: 10-15 meters (unobstructed)
- Audio Decoding: AAC, SBC
- Frequency (Hz): 20Hz-20KHz
- Input Current: 5V/0.5A
- Output Current: 5V/40mAh (per earphone)

Precautions

1. Please prevent the earphones from falling, colliding, violently shaking, twisting, scratching, or being exposed to water and fire during use. Contains batteries and must not be exposed to sunlight, fire, or similar overheating environments.
2. Try to keep headphones away from magnets and avoid using the device in extremely cold, hot, dusty, and humid environments.
3. To avoid damaging hearing, please keep the volume at a moderate level and avoid listening to music at high volume for a long time. This can cause permanent damage or deafness to hearing. Please pay attention when driving, riding a bicycle, crossing the road, etc. Use with caution when concentrating.
4. Changes in product performance and functionality will not be notified separately. Please do not disassemble this machine without authorization to avoid damage.
5. After charging is complete, please unplug the charging cable from the body to avoid keeping the product in a charging state for a long time. The output voltage and current of the charger shall not exceed 5V/1.5A. If the output voltage and current of the charger exceed the specified limit, this will cause serious damage to the product, and the product warranty will also be invalidated.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with