


# 157G铜版纸过哑膜 风琴折

## 55x55mm



### WIRELESS EARBUDS OPERATION INSTRUCTIONS

#### L/R

- Turn on: long press earbud 2S  
Turn off: long press earbud 6S
- Play/Pause: tap earbud once
- Answer/Hang up: tap earbud once
- Reject: long press earbud 1.5S
- Voice assistant: long press earbud 3S
- Previous track: tap earbud twice
- Volume - : tap earbud three times
- Next track: tap earbud twice
- Volume + : tap earbud three times

### WIRELESS EARBUDS INDICATOR LIGHT

- Turn on: blue light turns on once  
Turn off: light is on 1S
- Pairing: red and blue lights flash alternately
- Music play: no lights
- Call status: no lights

- Disconnected: red and blue lights flash alternately
- 1 light: means 25% battery
- Charging: red light is always on
- Fully charged: light off

### BLUETOOTH NECKBAND HEADPHONES OPERATION INSTRUCTIONS

- Volume "+" button
- Volume "-" button
- Power Button
- Long press power button 2S to turn on/off
- Short press power button
- Short press power button
- Long press 1.5S "-" button
- Long press 1.5S "+" button
- Click volume +
- Click volume -
- Short press power button
- Long press power button 1.5S
- Triple-click power button

### BLUETOOTH NECKBAND HEADPHONES INDICATOR LIGHT

- Pairing: red and blue lights flash alternately
- Disconnected: red and blue lights flash alternately
- Call status: no lights
- Charging: red light is always on
- Fully charged: blue light is always on
- Music play: no lights

### WIRED EARBUDS OPERATION INSTRUCTIONS

- Volume "+" button
- Power Button
- Volume "-" button
- Click volume +
- Click volume -
- Short press power button play/pause
- Short press power button answer/hang up
- Short press power button 2 times to next track
- Short press power button 3 times to previous track

### BLUETOOTH EARBUDS PRECAUTIONS:

#### 1: The sound is particularly low?

A: Because of the differences about the mobile phone's functions, when your earbuds is connected to the mobile phone's Bluetooth, please click the setting button on the phone Bluetooth signal behind, and then open: "Bluetooth device volume sync with mobile phone"

#### 2: Only one earbuds works? Can't pair automatically

A: Step 1: Please turn off the earphone or put the earphone into the charging case, and then delete this bluetooth signal in the bluetooth settings of the mobile phone.  
Step 2: Please take the two earphones out of the charging compartment at the same time, and then observe the indicator lights of the two earphones. The indicator lights of the two earphones flash red and blue alternately at the same time, indicating that the two earphones are being paired. When the pairing of the earbuds is completed, if only one earbuds indicator lights flashes red and blue, it means that the earbuds is waiting to connect the Bluetooth of the mobile phone.  
Step 3: The mobile phone Bluetooth searches for signals, and connects the earbuds. After the earbuds is connected, the earbuds indicator lights turn off.  
Step 4: If you failed above the steps, please contact customer service to replace it for you.

#### 3: Why the earbuds can't be used?

A: Step 1: Please charge the earbuds. Because the earphones have been out of the factory for a long time, they may be out of power.  
Step 2: If the first step failed, please contact customer service to replace it for you.

#### 4: How to check if the earbuds is fully charged?

A: When the earphone is charging, the red light of the earphone is always on that indicate the earphones is charging. When the earphones is fully charged, the blue light of the earphones is always on.

#### 5: Frequent disconnection

A: You often experience disconnection at airports, high-speed railway stations, subways, trains and other places, due to disturbance of the magnetic field and signal shielding. It is recommended that you move to a new place use it. If your experience is not good, you can contact customer service for replacement and refund.

#### 6: Part of the battery indicator light does not light up

A: Step 1: Maybe your earphone charging box needs to be charged, please observe the indicator light after fully charged (When using it for the first time, please charge the charging box for a while). If the operation is failed after the step 1, please contact customer service for replacement or refund.

#### 7: Headphones are slippery and easy to drop

A: The surface of our earphones is oil-injected and glossy. When you use it for the first time, there may be oil on the surface, so it is very slippery. When you wear it, please wear it in the correct way, it is not recommended that you use this item during strenuous exercise. If your experience is not good, you can contact customer service for replacement and refund.

### FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.  
This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
FCC Radiation Exposure Statement  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### After-sales commitment:

- 1: The headset cannot be charged
- 2: No sound from one earphone
- 3: The voice of the call is low or the call cannot be made
- 4: The sound of the two earphones is different
- 5: Broken soon
- 6: The magnetic force of the earphone box is too strong to take out
- 7: The earphones are slippery and cannot be taken out
- 8: Headphones cannot be paired with each other
- 9: The usage time of the headset does not match the description
- 10: The outer packaging is damaged
- 11: The earphones are easy to slip out of the ears
- 12: The earphones cannot be used normally when exposed to rain/dropped in water

If you meet above situations, you can contact our 24-hour online customer service for replacement or full refund. The products sold by BACKWIN provide 2-year warranty, if there is any problem, we will replace a new one for you.

Contact information: Amazon Email: info@backwin.com

AUTHORIZED BUSINESS / 總經銷  
BACKWIN TECHNOLOGY CO., LIMITED (HQ)  
OPERATOR / 運營商  
GUANGZHOU BACKWIN TECHNOLOGY CO., LIMITED  
廣州百音電子有限公司  
ADD: 501, 5th Floor, Jinhuo Building, Jinbao E-commerce Park, No. 3,  
Jinbao Road, Baiyun Lake, Baiyun District, Guangzhou, CN  
地址: 廣州市白雲區白雲湖金寶路三號金寶電商樓5樓501  
Hotline: +86-20-36610959 E-mail: info@backwin.com



www.backwin.com