


尺寸: 145*105 mm

Wireless Keyboard and Mouse Combo



User Manual

Keyboard Specifications

Working Voltage: 3 V
Working Current: 5 mA
Number of Keys: 105 keys
Battery: 2 x AAA
Product Weight: 393g
Keyboard Dimension: 388 x 132 x 18.6mm

Mouse Specifications

Working Voltage: 1.5 V
Working Current: 10 mA
Battery: 1 x AA
DPI Levels: 800/1200/1600 DPI
Product Weight: 57g
Mouse Dimension: 107 x 62 x 36 mm


Package Contents

1 x Wireless Keyboard
1 x USB receiver (inside the battery slot)


1 x Wireless Mouse
1 x User Manual

Compatible Systems


Windows 2000/XP/Vista/7/8/10/11

Product Overview

Num Lock Indicator
Caps Lock Indicator
Power Indicator
DPI Button



Keyboard Switch
Battery Cover




Mouse Switch
Battery Cover
(The USB receiver is inside the battery slot)

Hot keys and media keys

Fn+ F1	Brightness down	Fn+ F7	Previous Track
Fn+ F2	Brightness up	Fn+ F8	Play/Pause
Fn+ F3	Desktop Multi-Window Preview	Fn+ F9	Next Track
Fn+ F4	Show Desktop	Fn+ F10	Mute
Fn+ F5	Web/Home	Fn+ F11	Volume down
Fn+ F6	Search	Fn+ F12	Volume up
Fn+ Delete	Screen Lock		Calculator

Operation Methods

1. Remove the back covers from the keyboard and mouse, take the USB receiver out of the mouse.
2. Insert 2* AAA batteries into the keyboard battery slot, and another 1* AA batteries into the mouse, then put the covers back on.
3. Plug the receiver into the USB port of the computer and the two devices will be connected to your computer automatically after waiting for several seconds.

Switching DPI

The default DPI for the mouse is 1200DPI. By pressing the DPI Button, you can toggle the DPI of 800DPI, 1200DPI, 1600DPI.

Power Saving Mode

The keyboard will automatically go to sleep after 5 minutes and the mouse go to sleep after 15 minutes of inactivity. Press any button of keyboard and mouse to activate them.

Troubleshooting

If the keyboard doesn't work properly, please try the following:
1. Unplug the receiver from the computer.

2. Press the and keys at the same time, and then the power indicator will open.

3. Plug the receiver back into the USB port of computer.
4. The keyboard will reconnect to the computer.

If the mouse cannot work properly, please try the following:
1. Unplug the receiver from the computer.
2. Plug the receiver back into the USB port of computer.
3. The mouse will reconnect to the computer after waiting for several seconds.

IMPORTANT SAFEGUARDS & PRECAUTIONS

1. SAVE THESE INSTRUCTIONS—This sheet contains important safety and operating instructions.
2. Remove the batteries if the product is not going to be used for a long period of time.
3. For indoor use only. Never expose to direct sunlight or wet weather conditions.
4. Do not use if the equipment is damaged.
5. Do not disassemble the product. Disassembly may result in a risk of safety hazards.
6. Do not throw or shake the product.



Made in China

EN-1

EN-2

EN-3

EN-4

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.