

Precautions for using speakers

Power on/off-

Press and hold the power button in the shutdown state, and the product will automatically turn on. When the TF card is not inserted, it will enter Bluetooth mode by default, and the voice prompt will be "Bluetooth mode". Press and hold the power button to turn off the device.

Bluetooth connection-

Open the Bluetooth settings on your phone and search for the device name, then pair and connect. After successful connection, a prompt sound will sound and the blue light will remain on.

Mobile playback-

After a successful Bluetooth connection, open the music player on your phone, download your favorite songs or accompaniments to play, and adjust the volume to the appropriate level on your phone.

Tf card playback-

Insert the TF card into the device, and the device will automatically play music from the TF card.

Sound adjustment-

The volume can be adjusted through the buttons on the device control panel.

Charging-

Connect the standard charging cable to the charger for charging. The red light will remain on during charging and turn off when fully charged.

Precautions

1. Please disconnect the charger and turn off the machine before cleaning.
2. Non professionals are not allowed to disassemble the equipment on their own to avoid machine malfunctions and loss of warranty rights
3. Do not place the device in direct sunlight to avoid premature aging of electronic components.
4. Avoid using in dusty or dirty environments (dust can easily cause equipment failure)
5. Do not place the device in an environment that is too cold or too hot, as it may cause the device to malfunction.
6. It is recommended that the environmental temperature of the device should not exceed -10 °C -40 °C, with a relatively moderate range of 10% -95%.
7. Please do not insert any items into the device to avoid causing short circuits or circuit damage to the components
- Do not spill any liquid onto this product.
8. Avoid friction and impact between the device and hard objects to prevent surface scratches, detachment, or other hardware damage.
9. The product must not be exposed to environments such as sunlight, fire, or similar overheating conditions.
10. This product is prohibited from disassembly, impact, compression, or being put into fire. If the battery malfunctions severely, do not continue to use it.
11. This manual contains important information, please keep it confidential.

Bluetooth connectivity

1. Press and hold the power button on the speaker to turn it on. The voice prompts "Bluetooth mode" and the indicator light flashes. If the connection is successful, the blue light stays on.
 2. Turn on your phone's Bluetooth and scan it. Once you find the "Mini01" device, pair it and connect it. Once connected, you can hear it
 - The device emits a successful connection prompt sound.
- Note: After the device is connected to the phone once, Bluetooth has a memory function and will automatically connect after turning on. If you need to disconnect, you can disconnect Bluetooth through the phone settings.

Speaker parameters

Bluetooth version: 5.3 version Horn diameter: 40mm
Speaker power: 5W Working voltage: 3.7V
Frequency range: 20Hz-20kHz
Power adapter: DC5V <= 1A (compatible with mobile phone chargers)
Charging time: approximately 2.5 hours

Production information


Product Name: Portable Bluetooth Speaker
Product model: Mini01

Note: Our company's products are constantly innovating, and any changes are subject to change without prior notice

56*75mm 12P

Portable Bluetooth speaker operation instructions


Mini



Welcome to use

Thank you for purchasing the portable Bluetooth speaker. This speaker adopts advanced industry technology and has strong compatibility. Simply connect an audio playback device to easily enjoy a high-quality listening experience. Wishing you a pleasant use!

Function Introduction



- ① speaker
- ② Previous song key: Short press the previous song.
- ③ Long press the accompaniment to gradually decrease the volume
- ④ Mode key: Short press to switch Bluetooth/TF card
- ⑤ Key: Short press to play/pause
- ⑥ Long press to turn on/off
- ⑦ Next song key: Short press one song.
- ⑧ Long press the accompaniment to gradually increase the volume
- ⑨ MIC
- ⑩ Indicator light: Charging red light, Full of red light turning off.
- ⑪ Bluetooth waiting for connection, blue light flashing.
- ⑫ Successfully connected, the blue light stops on
- ⑬ Silicone dust plug
- ⑭ TF card
- ⑮ Type-C
- ⑯ Jacket
- ⑰ super magnet

Accessory diagram



Speaker



Type-C charging cable



Instructions

Parts list

Speaker
1pcs

Type-C
1pcs

Operation instructions
1pcs

—		—
⊕	<p>FCC Statement:</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and</p> <p>(2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. <p>Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p>	⊕