Specifications

Frequency:	433.39 MHz
Security:	128-bit AES encryption
Range:	up to 50 metres
Battery life:	up to 3 years
Battery type:	Eveready AA Lithium 1.5V x 2 (not Included)
Important:	Use only AA 1.5V Lithium batteries – do not use Alkaline batteries

e-LOOP Mini Fitting Instructions

Before fitting the e-Loop, you will need to fit the 2 x AA batteries and screw the bottom plate to the e-Loop using the M3 screws supplied. Ensure all screws are tight.



Step 1 – Fitting e-LOOP Mini base to driveway

1. Bolt the mounting plate to the driveway using the dyna bolts supplied, facing the Arrow towards the gate.

Step 2 – Coding e-LOOP Mini

1. Hold the e-Loop next to the antenna of transceiver
2. Now press and release the CODE button on the Transceiver. The e-Loop will flash the Yellow LED and the Transceiver will flash the Blue LED 3 times. The system is now coded.

Step 3 – Fitting e-LOOP Mini to base plate

(Refer to Diagram on the right)

1. Now fit the e-Loop to the base plate. Make sure the Arrow sticker underneath also faces the gate – this will ensure the keyway is aligned. The e-Loop will become active after 3 minutes.

NOTE: Never fit near high voltage cables, this can affect the e-Loop's vehicle detection and radio range capabilities.

Microtech Designs
enquiries@microtechdesigns.com.au
microtechdesigns.com.au

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.