

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

## Battery Safety Information:


- Ensure that battery polarity is correct.
- Use only batteries of the type recommended (or equivalent).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Rechargeable batteries are to be recharged by Adult only.
- Remove used-up batteries immediately.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit terminals.
- Dispose of batteries safely. Do not dispose of batteries (or products containing non-rechargeable batteries) in fire, as batteries may explode or leak.



This device complies with the Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.



CAR BATTERY: RECHARGEABLE LITHIUM BATTERY (INCLUDED)  
CONTROLLER BATTERY: 2 X 1.5V AA (NOT INCLUDED)

**WARNING:**  
CALIFORNIA PROPOSITION 65 WARNING:  
This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).



**DISTRIBUTED BY:**  
**HYPER TOY COMPANY**  
**1-866-204-9737** Toll Free  
177 Malaga Park Dr. Malaga, NJ 08328


**HYPER TOY CO**  
[help@hypertoys.com](mailto:help@hypertoys.com)

© Copyright 2024. HyperToys

This model is approved by Toyota Motor Corporation.

</

## CONTENTS



Vehicle




Remote Controller



Instruction Manual



Dropper




3.7V 600 mAh  
Rechargeable Battery




USB Charging Cable

## BATTERY INSTALLATION



Back of Remote Controller


- 1) Open battery cover by hand.
- 2) Put 2 X 1.5V AA batteries in the battery slots with correct polarity.
- 3) Close the battery cover.



Bottom of Vehicle


Charging the Battery: 90 minutes

- 1) Connect USB charging cable to vehicle charging port.
- 2) Connect USB to any power output from USB plug / computer to charge the vehicle.




WHEN CHARGING, THE CHARGING LIGHT WILL  
KEEP FLASHING; WHEN FINISHED CHARGING,  
THE CHARGING LIGHT WILL TURN OFF.

## FUNCTIONS




HYPER TOY CO

**CAUTION:**  
PLEASE DO NOT DIRECTLY FILL  
WATER FROM WATER TAP!  
ONLY FILL BY DROPPER



Water Filling Hole



Steam Effect Device