


















材质	封面100g书写纸 内页80g书写纸	装订方式	
语言	英语、日语、德语	尺寸	108*150mm

<div><h1>Wireless Headphones</h1></div>	<div><h2>Main User interface</h2><div><div>1 Power on & Power off button/Play &Pause button /Voice Assistant button/ Answer & Hang up & Reject & Recall the call button</div><div>2 Volume +/- Next song</div><div>3 Volume -/Previous song</div><div>4 LDE indicator</div><div>5 3.5mm AUX port</div><div>6 Type-C charging port</div><div>7 Microphone</div><div>8 ANC ON/OFF/Transparent and Gaming/Normal mode button</div></div><h2>Operation</h2><div><div>Power on: Long press on on/off button for 3 seconds,the blue light stays on for 1 second and then the blue and red lights flash alternately</div><div>Power off: Long press on on/off button for 3 seconds,red light flashes 2 times</div></div><div><div>Note: Keep your cellphoiness and headphones within 15m;if the headphones were disconnected with the device,it will power off automatically after 5 mins</div></div></div>	<div><p>Open the bluetooth devices page inside settings.Search for“H03” and select it to pair,the blue light flashes for 5 seconds after connecting to the device.</p><div><div>Note: If the headphones connected the device once, and the bluetooth functions of device was open ,the headphones will be reconnected with last device automatically.</div></div><h2>Play / Pause music</h2><p>Short press the  Play/Pause</p><h2>Volume +/- Next song</h2><p>Short press the  button to increase the volume;Long press the  button to play the next song</p><h2>Volume -/Previous song</h2><p>Short press the  to increase the volume;Long press the  button to play the next song</p><h2>Voice Assistant</h2><p>Three -click the  to invoke Siri</p></div>	<h2>Calling</h2> <ul style="list-style-type: none">When a call comes in, short press the  in order to answer the call or long press it to reject it.During a phone call, short press the  to end the call and the headphone will resume its previousworking state.Press the  two times to call the last number.During a call, the volume can be controlled via themobile phone. <h2>ANC ON/OFF/Transparent and Gaming/Normal mode</h2> <ul style="list-style-type: none">Short press the  again to switch transparent mode, and the prompt tone is transparent on.Short press the  to switch ANC ON, and the prompt tone is ANC on.Short press the  again to switch ANC OFF, and the prompt tone is ANC off.Double-click the  to switch between game mode and normal modeWhen the ANC mode and transparent mode are on, the indicator light is green, and when the ANC mode is off, the green light goes out. <h2>Charging</h2> <ul style="list-style-type: none">There is a prompt tone when battery power low.Red light will be always on when headphones is being charged.After fully charged, red light off.
---	--	--	---