



117mm

599mm

<div><div>VIVILUMENS</div><div>Light Up Exquisite Life</div><div>Alarm Clock Bedside Lamp</div><div>USER MANUAL</div></div>	<div><div>1 PRODUCT INTRODUCTION</div><div><div><div><div>①</div><div>②</div><div>③</div><div>④</div><div>⑤</div></div><div><div>⑥</div><div>⑦</div><div>⑧</div><div>⑨</div><div>⑩</div></div></div><div><div>① Wireless charging area</div><div>② Bluetooth indicator light</div><div>③ Wireless charging indicator light</div><div>④ Alarm clock indicator light</div><div>⑤ Night light</div><div>⑥ USB output</div><div>⑦ Type-C input</div><div>⑧ Alarm clock button</div><div>⑨ Clock button</div><div>⑩ Volume + button</div></div></div><div><div>①</div><div>②</div><div>③</div><div>④</div><div>⑤</div></div></div>	<div><div>2 INSTRUCTIONS FOR USE</div><div><div>Power On/Off</div><div>1. Press and hold the power button for 3 seconds to turn the device on/off.</div><div>Bluetooth</div><div>1. When the device is on, press once to toggle Bluetooth.</div><div>2. Bluetooth enters pairing mode, and the indicator light flashes.</div><div>3. Open Bluetooth settings on your phone or device.</div><div>4. Search for "EZVALO M2411A" in the Bluetooth list.</div><div>5. When connected, a prompt sound will play.</div><div>6. In Bluetooth mode, double-press the power button to disconnect, and the indicator light will flash.</div><div>Wireless Charging</div><div>Charging Area: Place the phone horizontally, not vertically.</div><div>1. After powering on, place the phone (or earbuds) in the wireless charging area. The phone will charge normally, and the charging indicator will light up.</div><div>2. If the phone case has metal, please remove it before charging.</div><div>Note: 1. The wireless charging function requires a power connection.</div><div>2. Use a 9V=2A adapter for optimal charging performance.</div></div></div>	<div><div>Night Light</div><div>1. Press the light button once for the first brightness level.</div><div>2. Press the light button again for the second brightness level.</div><div>3. Press the light button a third time for the third brightness level.</div><div>4. Press the light button a fourth time to turn off the night light, and the cycle repeats.</div><div>Adjusting Volume</div><div>1. In Bluetooth mode, press the volume - button to decrease the volume.</div><div>2. In Bluetooth mode, press the volume + button to increase the volume.</div><div>3. In alarm/clock setting mode, press the volume - button to decrease the number.</div><div>4. In alarm/clock setting mode, press the volume + button to increase the number.</div><div>Clock Settings</div><div>1. In clock mode, press to adjust brightness (3 levels - 2 levels - 1 level - off, cycling).</div><div>2. Press and hold the clock button to set the 24-hour clock.</div><div>3. When the hour flashes, press volume + or - to set the hour.</div><div>4. Press the clock button to save and enter minute setting (minutes flash).</div><div>5. Press volume + or - to set the minutes.</div><div>6. Press the clock button to save and return to the display.</div><div>Note: During clock setting, if no operation for 1 minute, current clock display will be auto - saved.</div></div>
---	---	---	---