


B35S

HELMET BLUETOOTH HEADSET

USER MANUAL



PRODUCT INTRODUCTION

In order to make riding safer and easier, the B35S Bluetooth helmet headset is designed for taking phone calls and listening to music or navigation while riding. The advanced CSR Bluetooth chipset and the integrated headphone amplifier provide a better audio experience regardless of use type. The delicate, small, and water-proof design makes the B35S an amazing riding companion.

PRODUCT PARAMETERS

Bluetooth Chipset Version: EDR Bluetooth CSR 8635	Battery Capacity: 950mAh
Frequency: 2.4GHz	Working Duration: ~40 hours
Bluetooth Profile: A2DP and AVRCP	Charging Voltage: DC 5V/210mA
Amplifier: HT4832Q	Maximum Mobile Phone Distance: 10 m/30ft

ITEMS INCLUDED



BUTTON FUNCTIONS

“+” ● Short press the plus button for volume increase.
● Long press the plus button to change to the next song.
“-” ● Short press minus button for volume decrease.
● Long press the minus button for the last song.
“U” When In Standby/Listening to Music/Listening to Navigation
● Short press the multi-function button to play and pause music.
● Long press the multi-function button to end the last outgoing call.
Incoming Call
● The B35S will automatically answer the incoming calls if no input is given within 10 seconds.
● Long press the multi-function button for 2 seconds to reject an incoming call.
● Short press the multi-function button to answer an incoming call.
Calling
● Short press the multi-function button to hang up after calling.

FUNCTIONAL OPERATION

Boot: Long press “U” button for 2 seconds.
Shutdown: Long press “U” button for 3 seconds.
First Time Paring:
Step 1: Long press “U” button for 2 seconds to boot the device and wait for the red and blue LED lights flash alternately.
Step 2: Open the mobile device Bluetooth list, select “B35S” and connect. Once connected, only the blue LED light will flash.
Automatic Paring: Open the Bluetooth settings page of the last connected phone. Long press the “U” button for 2 seconds to boot the B35S, then the device and Bluetooth phone will automatically be paired within 15 seconds as indicated by the blue LED light softly flashing.
Automatic Power Off: If the device has no previous connections with any nearby Bluetooth devices for 5 minutes, it will automatically power off.
BATTERY CHARGING
● Connect the device to your PC USB or any USB charge socket to charge the battery.
● The red LED light indicates that the unit is charging.
● When charging is completed, the red LED light will turn blue.

HARDWARE RESET

Charge the device if the system has any issues.

HOW TO MOUNT THE HEADSET

1. Mounting headset device on the helmet.
Main Method: Use the provided mounting clip to find a suitable position on the edge of the helmet and clamp the mounting clip to the helmet.
Alternate Method: You can use Velve to mount the device on the edge of the helmet.

Fig. 1 Fix the mounting clip to the helmet.
Fig. 2 Insert the device onto the mounting clip.
Fig. 3 Remove the device from the mounting clip by pressing the red button.

COMMON FAULTS AND SOLUTIONS

Fault Symptom	The Reason	How to Fix the Issue
The connection is suddenly interrupted	There is an obstacle stopping the signal path or the distance is beyond the effective distance between the two devices or make sure the B35S and phone are within the effective distance	Clear any obstacles or make sure the B35S and phone are within the effective distance
Automatic shut-down	The battery is low or the B35S has been under unpaired mode for over 5 minutes	Charge with an accessory charging cable or connect the available Bluetooth device
Monosyllabic/murmurs or unable to call	Audio input or output exception	Check the audio output with the input plug in just the right place
All buttons ineffective	Hardware failure	Reset the hardware by charging the headset with the USB cable

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Warranty Card

User Name: _____ Tel: _____
Address: _____ Purchase Date: _____ Model: _____
Problem Description: _____
Date: _____

QUANTIFIED CERTIFICATE
CHECKER: _____ DATE: _____




455mm X 95mm

B35S

BLUETOOTHヘルメットヘッドセット

取り扱い説明書



製品紹介

B35Sは弊社最新のヘルメット用イヤホン製品です。本体とイヤホンが分離される設計で、運転中の操作は楽になり、音質も飛躍的に向上しました。その上、従来の薄型イヤホンと長時間待機も対応しています。この商品を十分に活かすため、利用前は必ず本書をお読みください。また、お読みの後、いつでもご覧になるところに保管してください。

製品仕様

Bluetoothチップ: EDR BT CSR 8635	電池容量: 950mAh
周波数: 2.4GHz	利用時間: ~40時間
Bluetoothプロファイル: A2DP and AVRCP	充電電圧/電流: DC 5V/210mA
アンプ: HT4832Q	通信距離: 10メートル以内

内容リスト



ボタン機能

“+” ● 2秒長押して製品を起動し、利用可能なデバイスがない場合は待機状態になり、LEDライトは赤色で交互に点滅します。
● 電源オフの時で2秒長押して電源を切れます。
● 1秒長押してSIRIを起動させます。(アップル端末のみ、一部のアンドロイド端末で音声アシスタントを起動させます。)
● 電源オンの状態、Bluetooth未接続の状態で電源ボタンを2回に連続押して、言語を変更します。

充電について

● 付属のケーブルを利用してPCやUSBスマートの充電器と接続して充電します。
● 充電中、電源は自動オフします。電源ボタンを押して製品を起動できます。
● 充電中にLED指示ライトは赤と表示されます。
● 充電が完了した後、LED指示ライトは青になります。

リセット

● 商品はフリーズなど機能に異常がある時、充電をして商品を強制的に電源オフできます。電源を再起動したら、商品が正常になります。

取付方法

1. 本製品本体をヘルメットに取り付けます。
取付方法: 付属の固定クリップを使用してヘルメットの縁に適切な位置を見つけて、固定クリップをヘルメットに挟んで本体に固定します。

図1. 固定クリップをヘルメットに固定します。
図2. 本体を固定クリップに差し込みます。
図3. 取り出し時に赤色の位置を押さえて本体を上にします。

ペアリング

電源入れ: “U”ボタンを2秒長押し 電源切れ: “U”ボタンを3秒長押し
はじめてのペアリング:
ステップ1: “U”ボタンを2秒長押して起動し、LEDライトは赤青で交互に点滅してペアリングモードに入ります。
ステップ2:スマートのBluetoothリストを開き、「B35S」を選択すると、本製品の青色LEDライトがゆっくりと点滅することで、「connected」の提示音があり、ペアリングが成功したことを示します。
自動ペアリング:
最後にペアリングしたデバイスのBluetoothをオンにし、“U”を2秒長押しして製品を起動します。その後、本製品とデバイスが15秒内で自動でペアリングされます。青色LEDライトがゆっくりと点滅することで、ペアリングが成功したことを示します。
自動電源切り:
5分以内にBluetoothが接続されていない場合、本製品は自動的に電源をオフにします。

ご注意

1. 本製品に適用される保存温度は-20°Cから50°Cまでです。温度が高すぎるや低すぎる環境内で保存すれば製品の寿命が減少する可能性があります。
2. 爆発の恐れがありますので、本製品に火をつけないでください。
3. シートを防ぐため、本体内部に水が直接入らないようにしてください。
4. 長時間に本製品を利用しない場合、乾燥の場所に保管し、定期的に製品を充電してください。(3ヶ月に1回充電する)

故障と対策

故障現象	原因	対策方法
急に信号が中断	送信経路の障害物があり、スマートと本製品との間の有効距離を超える距離が範囲内であることを確認する	送信経路を妨げる障害物があるか、またはスマートと本製品との間の有効距離を超過する距離が範囲内であることを確認する
自動電源切れ	バッテリー残量が少ない、5分間内にペアリングされていない	充電するスマートとペアリングする
片方だけ音が出たり、電話ができない	イヤホンの入力/出力が異常になる。	イヤホンの接続が正しい位置にしっかりと挿したかを確認する。
すべてのボタンは効かない	電量不足	充電する

保証書

本保証書は、保証期間中に本製品を保証するもので、付属品(充電器など)は保証の対象になりません。保証期間内に本製品が故障した場合は、保証規定によって無償修理いたします。

1. 本保証書の有効期間はお買い上げ日より1年です。
2. 2次の修理等は保証期間内であっても有償となります。
● 取扱い方法が不適当のために生じた故障。
● 天災(火災、津波等)によって生じた故障。
● 故障の原因が本製品以外の他の機器にある場合。
尚、当社が修理をした部分が再度故障した場合は、保証期間外であっても、修理した日より3ヶ月以内に限り無償修理いたします。

3. 本製品の故障、または使用上におけるお客様の直接、間接の損害につきましては、弊社は一切の責任を負いかねますのでご了承ください。本保証書は、保証規定により無償修理を約束するためのもので、これよりお客様の法律上の権利を制限するものではありません。

本保証書は、保証規定により無償修理をお約束するものです。
お買い上げ日 年 月 日 販売店名 _____

■修理を依頼される前に
故障などお問い合わせになったら、まず取扱説明書をよくお読みのうえ、もう一度ご確認ください。