




悬浮蓝牙键盘说明书

非常感谢您购买本款悬浮蓝牙键盘，我们建议使用前请仔细阅读这些说明，以利于更加了解该产品。



无线连接


1. 将11 iPad Pro吸附到键盘上。



2. 开启平板蓝牙搜索，拨开键盘电源开关到 ON.ON/OFF，蓝牙灯亮起。



3. 键盘蓝牙灯闪烁，在平板“其他设备”里点击“Bluetooth Keyboard”进入视窗后点击“配对”，配对成功后，蓝灯熄灭。




*注：配对成功后，下一次使用键盘将自动连接平板。



- 误触配对键盘：需重新配对。
- 若平板蓝牙界面“我的设备”出现多个“Bluetooth Keyboard”，可点击右边①然后点击“忽略此设备”消除。
- 绝大部分未知原因的使用故障可通过重启平板或键盘解决。
- IOS触摸手势可以参考说明书。
- 平板吸附到键盘后，键盘才可以进行配对和正常工作。
- 键盘在长时间无蓝牙连接后，会进入深度睡眠状态以降低功耗；按任意键唤醒。

键盘标识



快捷键

快速切换语言输入法

control+空格	切换输入法
control+箭头	切换窗口
control+tab	切换标签
control+cmd+空格	调出表情与符号
cmd+Z	撤销
cmd+X	切换
cmd+C	拷贝
cmd+V	粘贴
cmd+A	全选
cmd+S	保存
cmd+F	查询
cmd+shift+3	截取全部屏幕到文件
cmd+shift+control+3	截取全部屏幕到剪贴板
cmd+shift+4	截取所选屏幕区域到一个文件
cmd+shift+control+4	截取所选屏幕区域到剪贴板

快捷符号

option+R:	®
option+G:	©
option+=:	≠
option+>:	≥
option+<:	≤
option+/:	÷
option+P:	π
option+V:	√
option+J:	△
option+Z:	Ω
option+X:	~
option+M:	μ
option+S:	β
option+W:	Σ
option+5:	∞

在应用程序中：

cmd+H	隐藏当前应用程序窗口
cmd+option+H	隐藏其他应用程序窗口
cmd+Q	退出最前面的应用程序
cmd+shift+Z	重做，也就是撤销的逆向操作
cmd+tab	转到下一个最近使用的应用程序

文本处理：

cmd+B	切换所选文字粗体显示
cmd+右箭头	将光标移至当前行的行尾
cmd+左箭头	将光标移至当前行的行首
cmd+下箭头	将光标移至文稿末尾
cmd+上箭头	将光标移至文稿开头
option+右箭头	将光标移至下一个单词的末尾
option+左箭头	将光标移至上一个单词的开头
control+A	移至行或段落的开头

在文件中：

cmd+option+V	剪切文件
cmd+shift+N	新建文件夹
cmd+shift+G	调出窗口，可输入路径直达文件夹
cmd+O	打开所选项
cmd+上箭头	打开包含当前文件夹的文件夹
cmd+delete	将文件移至废纸篓
cmd+shift+delete	清倒废纸篓



在浏览中：

control+tab	转向下一个标签页
cmd+L	直接跳至地址栏
control+shift+tab	转向上一个标签页
cmd+=	放大页面
cmd+-	缩小页面

ISO触摸手势

	点按：用单指按下直至有点按感。		点按住：用单指按住。
	拖移：点按住项目，然后用手指在触摸板上滑动以移动它。		唤醒iPad：点按触控板或者如果您正在使用外接键盘，请按下任一按键。
	打开程序坞：用单指将指针轻扫过屏幕底部。		前往主屏幕：用单指将指针轻扫过屏幕底部。程序坞出现后，再次将指针轻扫过屏幕底部。
	显示侧拉：用单指将指针轻扫过屏幕底部。		打开“控制中心”：用单指移动指针以选择右上方的状态图标，然后点按，或者选择右上方的状态图标，然后单指向上轻扫。
	打开“通知中心”：用单指移动指针以上选择左上方的状态图标，然后点按，或者用单指将指针移过屏幕顶部中间附近。		向上或向下滚动：双指向上或向下轻扫。
	向左或向右滚动：双指向左或向右轻扫。		缩放：双指靠近放置，张开以放大，或者捏合以缩小。
	前往主屏幕：三指向上轻扫。		打开APP切换器：三指向上轻扫，停顿一下然后抬起手指，或者四指捏合，停顿一下然后抬起手指。
	在打开的APP之间切换：三指向左或向右轻扫。		打开“今天”视图：在主屏幕或锁定屏幕可见时，用双指向右轻扫。
	从主屏幕打开搜索：双指向下轻扫。		辅助点按：双指点按主屏幕上的图标。邮箱中的邮件以及“控制中心”中的“相机”按钮等目录，以显示其快速操作菜单。可以按住Control键并点按触控板。

Suspension Bluetooth Keyboard Manual





wireless connection


1. Snap the 11iPad Pro to the keyboard.



2. Turn on the tablet Bluetooth search, turn on the keyboard power switch until the ON.ON/OFF Bluetooth light is on.



3. The bluetooth light of the keyboard flashes, click "Bluetooth Keyboard" in the "Other Devices" of the tablet to enter the window and click "Pair", after the pairing is successful, the blue light goes out.




* Note: After successful pairing, the next time you use the keyboard, it will automatically connect to the tablet.



1. Accidentally touch the pairing keyboard: need to pair again.
2. If there are multiple "Bluetooth Keyboard" in "My Device" on the Bluetooth interface of the tablet, you can click on the right , then Click "Forget this device" to remove.
3. Most of the use failures of unknown reasons can be solved by restarting the tablet or keyboard.
4. For IOS touch gestures, please refer to the manual.
5. After the tablet is attached to the keyboard, the keyboard can be paired and work normally.
6. After a long time without Bluetooth connection, the keyboard will enter a deep sleep state to reduce power consumption; press any key to wake up.

keyboard identification



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

hot key

Quickly switch language input method

control+ space	switch input method
control+ arrow	switch windows
control+tab	switch tab
control+cmd+space	bring up emojis and symbols
cmd+Z	revoke
cmd+X	toggle
cmd+C	copy
cmd+V	paste
cmd+A	select all
cmd+S	save
cmd+F	inquire
cmd+shift+3	capture all screen to file
cmd+shift+control+3	capture entire screen to clipboard
cmd+shift+4	capture selected screen area to a file
cmd+shift+control+4	capture selected screen area to clipboard

shortcut symbol

option+R:	®
option+G:	©
option+=:	#
option+>:	≥
option+<:	≤
option+/:	÷
option+P:	π
option+V:	v
option+J:	Δ
option+Z:	Ω
option+X:	~
option+M:	μ
option+S:	β
option+W:	Σ
option+5:	∞

In the application:

cmd+H	hide the current application window
cmd+option+H	hide other application windows
cmd+Q	exit the frontmost application
cmd+shift+Z	redo, the reverse of undo
cmd+tab	go to the next most recently used app

Text processing:

cmd+B	toggle selected text bold
cmd+right arrow	move the cursor to the end of the current line
cmd+left arrow	move the cursor to the beginning of the current line
cmd+down arrow	move cursor to end of document
cmd+up arrow	move the cursor to the beginning of the document
option+right arrow	move the cursor to the end of the next word
option+left arrow	move the cursor to the beginning of the previous word
control+A	move to the beginning of a line or paragraph

in the file:

cmd+option+V	cut file
cmd+shift+N	new folder
cmd+shift+G	bring up the window, you can enter the path directly to the folder
cmd+O	open selected
cmd+up arrow	open the folder containing the current folder
cmd+delete	move files to Trash
cmd+shift+delete	empty the Trash

browsing:

control+tab	go to the next tab
cmd+L	jump directly to the address bar
control+shift+tab	go to previous tab
cmd+=	enlarge the page
cmd+=	zoom out

ISO touch gestures

	tap: press with one finger until it feels slightly clicky		tap and hold: press and hold with one finger
	drag: tap and hold an item, then swipe your finger across the touchpad		wake up iPad: tap the trackpad or if you are using an external keyboard, press any key
	open the dock: swipe the pointer across the bottom of the screen with one finger		go to the Home screen: swipe the pointer cross the bottom of the screen with one finger and when the Dock appears, swipe the pointer across the bottom of the screen again
	display slide over: swipe the pointer across the bottom of the screen with one finger		open control center: move the pointer with one finger to select the status icon in the upper right, then tap, or select the status icon in the upper right, then swipe up with one finger
	open notification center: move the pointer with one finger to select the status icon in the upper left, then tap, or move the pointer over the middle attachment at the top of the screen with one finger		scroll up or down: swipe up or down with two fingers
	scroll left or right: swipe left or right with two fingers		zoom: place two fingers close together, pinch to zoom in, or pinch to zoom out
	go to the home screen: swipe up with three fingers		open the app switcher: swipe up with three fingers, pause, then lift your finger, or pinch with four fingers, pause, then lift your finger
	switch between open apps: three-finger swipe left or right		open today view: when the home or Lock screen is visible, swipe right with two fingers
	secondary tap: two-finger tap on icons on the Home screen, messages in mailboxes, and categories such as the camera button in Control Center to display their Quick Actions menu. You can hold down the CONTROL key and click on the monitor panel		