

TPS User manual


Jinwu. Zhang

2024/8/12



WILLING TPS3.3 User manual

- center frequency: 433.92MHz;
- RF modulation mode: FSK;
- The RF baud rate: 9600kbps;
- Data encoding mode: Manchester Encoding ;
- Frequency offset range: $\pm 43\text{kHz}$;
- Operating Temperature Range : -40°C to 125°C ;
- level of protection : IP6K9K;
- Installation position: Rim & The tyre inside;
- Pressure range: 100~920kpa
- Crystal frequency: 26MHz
- Mass: $\leq 25\text{g}$
- Battery voltage: 3V



Note: the product model TPS3.3 on the label is fixed, other information will be changed with the change of customer information supplied by our company.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Installation requirements:

- ◆ Metal valve;
- ◆ Nut torque: 6 N*M;
- ◆ Installation process: Install the sensor in the edge hole, and then use the torque tool to fix the nut;





Thanks

谢谢您的聆听