

Bally

SPORT EDGE SENSOR



FCC statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This portable equipment with it's antenna complies with FCC's radiation exposure limits set forth for an uncontrolled environment. To maintain compliance, follow the instructions below:

1. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. Avoid direct contact to the antenna, or keep contact to a minimum while using this equipment.

This device must be professionally installed

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Supplier's Declaration of Conformity

Unique Identifier : BOXY01

FCC-ID : 2A94O-BOXY01

Party issuing Supplier's Declaration of Conformity

Bally's corporation
100 Westminster Street
Providence, Rhode Island
RI 02903, United States
Phone : 401.475.8474

Responsible party – U.S. Contact Information


100 Westminster Street
Providence, Rhode Island
RI 02903, United States
Phone : 401.475.8474

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Switching OFF the sensor

Push the button till the two blue LEDs switching OFF



Switching ON the sensor

Push the button till the Activity LED start blinking green




Auto-shutdown

The sensor is set to automatically switch OFF after 2 hours of no motion state and no gateway connectivity


Hardware Reset

Push and hold the button to perform a hard reset



Battery Charging

Place the sensor on a Qi standard wireless charger.
The button/Leds area should be placed outside the charging circle.
The POWER Led should start blinking green



Nota : If the Green Power Led doesn't start, slightly move the sensor on the charger pad to find the charger coupling location

The sensor is fully charged when the Green POWER Led is fixed



POWER LED



LED OFF
Normal operation



BLINKING GREEN
Device is charging



FIXED GREEN
Charging completed



BLINKING YELLOW
Device is charging + Power Error



FIXED YELLOW
Charging completed + Power Error



BLINKING PINK
Power Error



BLINKING RED
Battery LOW – Please charge battery

ACTIVITY LED



LED OFF

Device is shutdown



BLINKING GREEN

IDLE state – Waiting for BLE connection



BLINKING BLUE

CONNECTED state – Device is connected to the gateway



BLINKING CYAN

SESSION STARTED state – Device is connected and sending motion data to the gateway



POWER LED + ACTIVITY LED



BOTH LEDs BLINKING BLUE

Firmware Update



BOTH LEDs FIXED BLUE

Button is being pressed

Sensor Identification

Each sensor has a Unique ID to be identified by the Gateway

This Unique ID is a 8-digits ID

There are 3 ways to read the ID :

**Flash QR-Code with a
Smartphone or 2D scanner**



**Read the text below
the QR-Code**



Flash the NFC Tag located on the Top

