

Page 1

user's Guide

BA 64V

BURTON
Experience true audio excellence


BURTONAUDIO.COM

Page 2


Precautions

- Before using this machine for the first time, please read the user manual carefully and follow all operating instructions and precautions.
- Because the high voltage inside the machine is dangerous, do not repair it by yourself. All repairs and adjustments must be performed by professionals.
- The power source used in this machine must match the type indicated on the nameplate.
- The power supply on the socket must not be overloaded; the power cord should be placed where it cannot be stepped on, and items should not be placed on the power cord.
- Do not place this machine on a sofa, near unventilated places such as curtains, or in direct sunlight and humidity, and avoid dropping or subjecting this machine to shock.
- Unplug the machine from the power outlet before cleaning. Do not use thinner or other chemical cleaners, just wipe with a soft cloth.
- After the machine is turned off, if you do not use the machine for a long time or in a thunderstorm, please unplug the power plug from the power outlet.
- To avoid the risk of fire, electric shock, or product damage, do not expose the machine to rain, moisture, or dripping liquids, and do not place water-containing objects such as vases on the machine.
- Do not expose batteries or battery-installed devices to excessive heat, such as sunlight and fire.


Page 3



Page 4



Page 5



Page 6

Functional operation

1. POWER
After connecting the audio signal cable to the corresponding interface of the machine, plug in the power cable and turn the power switch to ON; the LED display will show the current working mode.

2. Working mode conversion
After powering on, short press the "LINE" button on the rear panel of the machine or the remote control audio source button to switch to different working modes; the LED display shows the working mode corresponding to the characters:BT = Bluetooth; PT = Optical input; CO = Coaxial input; LINE = auxiliary input; USB = USB playback; ARC = HDMI(ARC) input; IDI = aux input; CEC = CEC interface; *1 = IDI(M/ARC) interface; *2 = Coaxial input interface; *3 = CEC interface; *4 = LINE interface.

3. Volume button operation function
The remote control's "Volume + and "Volume -" long or short press can increase or decrease the volume, the LED display will show the corresponding volume level, the maximum level is 32.

4. Bluetooth operation method
This product will automatically enter the pairing mode when using the Bluetooth input mode for the first time. At this time, the LED display will show BT end flicker. You can directly use your Bluetooth playback device to connect to this product. When the connection is successful, a voice prompt "Bluetooth has connection". This product will automatically switch to pairing mode when no device is connected to Bluetooth mode. If you intend to switch to another Bluetooth playback device while the Bluetooth playback device that is currently connected, wait for the product to automatically switch to Bluetooth pairing mode, and then use the new Bluetooth playback device. Connect.

5. Connecting device description
The power signal of the left and right sides of the wall is connected to the power signal of the sound bar to cut off the machine, connect the machine to an easily accessible AC outlet. If you are in an unusual position, immediately unplug the power plug from the AC power.

6. Connecting device description
The distance between the holes on the left and right sides of the wall is 376mm, and the distance between the left and right screws is 24mm.

7. Connecting device description
Source selection button: Press to switch between AUX coaxial fiber input modes

Page 7

Page 8

Page 9

Page 10

Page 11

Page 12

Page 13

Page 14

Page 15

Page 16

Page 17

Page 18

Page 19

Page 20

Page 21

Page 22

Page 23

Page 24

Page 25

Page 26

Page 27

Page 28

Page 29

Page 30

Page 31

Page 32

Page 33

Page 34

Page 35

Page 36

Page 37

Page 38

Page 39

Page 40

Page 41

Page 42

Page 43

Page 44

Page 45

Page 46

Page 47

Page 48

Page 49

Page 50

Page 51

Page 52

Page 53

Page 54

Page 55

Page 56

Page 57

Page 58

Page 59

Page 60

Page 61

Page 62

Page 63

Page 64

Page 65

Page 66

Page 67

Page 68

Page 69

Page 70

Page 71

Page 72

Page 73

Page 74

Page 75

Page 76

Page 77

Page 78

Page 79

Page 80

Page 81

Page 82

Page 83

Page 84

Page 85

Page 86

Page 87

Page 88

Page 89

Page 90

Page 91

Page 92

Page 93

Page 94

Page 95

Page 96

Page 97

Page 98

Page 99

Page 100

Page 101

Page 102

Page 103

Page 104

Page 105

Page 106

Page 107

Page 108

Page 109

Page 110

Page 111

Page 112

Page 113

Page 114

Page 115

Page 116

Page 117

Page 118

Page 119

Page 120

Page 121

Page 122

Page 123

Page 124

Page 125

Page 126

Page 127

Page 128

Page 129

Page 130

Page 131

Page 132

Page 133

Page 134

Page 135

Page 136

Page 137

Page 138

Page 139

Page 140

Page 141

Page 142

Page 143

Page 144

Page 145

Page 146

Page 147

Page 148

Page 149

Page 150

Page 151

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.