



WiFi-6 Active AC Router



Quick-Start Guide

Certified Manufacturer
DEPIN LABS

Quick-Start Guide


Please scan the QR code for the complete product manual, or go to metablox.io/miner/guide for more detailed instructions.



What's in the Box

1. Router
2. Quick-start guide
3. Cable
4. Power adapter

Hardware Interface



Name	Usage
Power Port	For connecting the router to a power socket via the provided power adapter
2.5G SFP Socket	For fiber connection, transceiver module not included
2.5G POE WAN/LAN	RJ45 port with PoE, configurable between WAN/LAN (Defaulted as WAN)
1G LAN	Used for connecting your desktops and other wired network devices to the router
Reset Button	Short press to reboot. Press and hold for more than 5 seconds before releasing to reset the Router back to factory settings

Indicator LED



Indicator LED	Dual LED (Green, Orange)
No Light	Device not powered on
Orange (solid)	System booting up/ Upstream network not connected
Orange & White (alternating)	Startup completed, system pending configuration
White (solid)	Operating normally

Network Port LED	Dual LED (Green, Orange)
No Light	No physical connection to the Ethernet port
Green (solid)	Physical connection established to the Ethernet port
Green & Orange (flashing)	Ethernet port has network traffic

Internet Access & Registration

STEP Connect

1

Power on the router and connect its WAN port to the wall socket or the LAN port of the modem. The optical modem/broadband modem is provided by the broadband service provider.

STEP

2

- Download Metablox App and finish OpenRoaming profile setup.
- Connect to "Metablox-OpenRoaming" WiFi.
- From Metablox App, please click on "+ Register" on home page or My Miner page to register this device and follow on screen instructions to finish registration.



* To access private WiFi, please connect to "Metablox-Private" (default password is "metablox")

* How to manage your router's setting:

1. Enter gateway IP (default IP is 192.168.1.1) into your browser.
2. Log in using the username "admin" and the default password shown on your label sticker.

Mobile Application

Download Metablox mobile application.



App Store



Google Play



Need Support? Contact Us!

support@metablox.io

support@depinlabs.ai

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

The device for operation in the band 5150~5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems, within all European Union countries AT, BE, BG, CH, CY, CZ, DE, DK, EE, EL, ES, FI, FR, HR, HU, IE, IS, IT, LT, LU, LV, MT, NL, NO, PL, PT, RO, SE, SI, SK, TR, UK(NI).

ISED Statement:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device."

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

Modification:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

Toute modification non approuvée explicitement par le fournisseur de licence de l'appareil peut entraîner l'annulation du droit de l'utilisateur à utiliser l'appareil.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Operation of 5150-5350 MHz is restricted to indoor use only.

Le fonctionnement de 5150-5350 MHz est limité à une utilisation en intérieur uniquement.