

INSTRUCTION


1. short press  on cable to switch mode.
2. long press  on cable to power on/off.

NOTE

1. During use, if the switch can work normally, but the remote control cannot, you need to perform the code matching operation.
2. if the light is interfered by other remote controls or cannot be controlled remotely. Please power off and then power on again before performing code matching.

How to perform code matching operation: Press and hold the power button on the remoter for 3 seconds within 7 seconds of turning on the power, the light strip flashes 3 times with white light, indicating that the code (remote control) is matched.

SELV  **CE**



EN:Non-replaceable light source
DE:Nicht austauschbare Lichtquelle
FR:Source lumineuse non remplaçable

EN:Non-replaceable control gear
DE:Nicht auswechselbare betriebsgeräte
FR:Appareillage de commande non remplaçable

this product contains a light source of energy efficiency class F.

RoHS



FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.