

PILLOW SPEAKER

USER MANUAL



Bluetooth mode-

Pillow speaker bluetooth pairing instruction:

1. Holding the power key until speaker power-on, the light indicator will be blinked.
2. On your device, enable the Bluetooth feature
(Tip: the bluetooth feature is usually found in the setting menu)
3. Select your speaker from the device list-name is "PILLOW SPEAKER", Once paired, the indicator glows solid blue.

T-Flash mode-

Once insert T-Flash card, bluetooth mode will be switched to TFlash mode automatically.

Pillow speaker will play the music which stored in the T-Flash card.

(* Double click Power-key to switch between Bluetooth and T-Flash mode.

Bluetooth can not be connected under T-Flash mode.)

PC mode-

Simply press the power button once when connecting with computer via USB data cable, to access your T-flash data storage. You can freely add/remove the music/songs/files into your T-flash card in this mode. (T-flash card must be inserted in Pillow Speaker)

Playing/ Volume setting-

1. single click vol- or vol+ key to decrease or increase voice reminder if volume increase to maximum level.
2. Hold vol- or vol+ key to switch to previous/next song.
3. single click power key to play or pause the music.

Timer-

Triple click on power key to enable the function, click vol+ key once to turn off after half an hour. Double click on vol+ key to turn off after one hour. same applies when turning off with vol - key. (press once in hour mode to auto off in 30 minute, press twice to turn off the timer function)

Charging:

Insert charging plug, the red indicator will be lighted, blue light once charging Completed.

* Any queries, pls contact us: hello@bocoice.com

PILLOW SPEAKER

Warning:

- * To avoid charging warming and potential risks, the devices should not be charged while as playing music;
- * USB cable compatible with common Type C USB charger, like car charger, mini fan charger(**DO NOT USE FAST CHARGER**, and the charging voltage should not exceed 5 volts)

FCC Warning :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

duraMOBI

bocoice™

www.duramobi.com & www.bocoice.com

5.0

CE

RoHS



R 214-117739

FCC ID : 2A9HL-C807

