

## X7 Open Wireless Headphones

### [Battery low voltage detection]

When the battery voltage of the headset drops to 3.4V, the headset detects a low voltage, and every 20s, it will prompt "The battery is too low, please charge it in time".

When the battery voltage of the headset is as low as 3.3V, the headset detects a low voltage, and the headset automatically shuts down after 30 seconds.

### [Charging and Battery]

1. Before charging, please turn off the headset

2. Connect headset and charger(5V 100mA) via supplied charging cable

3. During charging RED indicator lights and BLUE indicator will lights on when full charged.

Warning: You must use the matching charging cable to charge the earphones. Using an incompatible charging cable may damage the earphones.

If the DC voltage must be 5V, the current is greater than 100mA (5V/100mA)

This headset uses a built-in non-removable rechargeable battery, do not attempt to remove the battery from the headset to avoid damage to the headset.

### Headphone Package Contents

- Headset 1pc
- product manual 1pc
- Charging cable 1pc

### Safety Precautions

In order to use this headset correctly and safely, please read this manual carefully before using

### [Note the following when using headphones]


1. Please reasonably control the volume and time when using headphones
2. Do not use the headset in a potentially dangerous environment to ensure safety
3. Try to avoid using headphones to listen to music, make or answer calls while driving
4. Please store the earphones out of the reach of children to avoid dangers
5. Avoid water in the earphones when grooming
6. Try to avoid continuously raising the volume, otherwise you can't hear the sounds around you. If you have tinnitus or turn up the volume too high, please adjust the volume to an appropriate volume.
7. If you feel obvious discomfort, irritation or other adverse reactions when using the headset, please stop using it immediately (60% volume is recommended)
8. Avoid storing or using the earphones in environments where the temperature is lower than -15°C (5°F) or higher than 55°C (131°F), otherwise the earphone or battery life will be shortened

### Headphone Overview

#### LED Indication:

| MODE          | BLUE LED                         | RED LED                        | VOICE GUIDE  |
|---------------|----------------------------------|--------------------------------|--------------|
| Pairing       | Blue & Red twinkle alternately   | Blue & Red twinkle alternately | Pairing      |
| Connecting    | Blue twinkle slowly              | Blue & Red twinkle alternately | Connected    |
| Turn on       | Blue & Red twinkle alternately   | Blue & Red twinkle alternately | Turn on      |
| Turn off      |                                  | Red lights on and off          | Turn off     |
| Disconnected  | Blue & Red twinkle alternately   | Blue & Red twinkle alternately | Disconnected |
| Incoming call | Blue twinkle slowly              | Non                            | Phone ring   |
| Talking phone | Blue twinkle slowly              | Non                            | Non          |
| Low voltage   | Blue twinkle quickly             | Non                            | Non          |
| Charging      | Blue lights on when full charged | Red lights on when charging    | Non          |

### [Headphone Description]



### Button: Definition

| BUTTON | FUNCTION    | EXPLANATION  |
|--------|-------------|--|
| On/Off | Turn on/off | Press 3 seconds to turn on or off<br>Incoming call: touch 1 time to answer or hold to refuse<br>During talking: touch 1 time to end the call<br>During playing music: touch 1 time to Play/Pause |

### [On/Off]

When the headset is off, press and hold for 3 seconds to turn on the headset;  
When the headset is on, press and hold for 3 seconds to turn off the headset;  
When headset disconnected and no any operation, it will automatic shutdown in 5 minutes

### [Bluetooth Pairing Steps]

1. Please control the distance between the Bluetooth headset and the mobile phone (or other devices used for connection) within 1 meter, the closer the better
2. Press and hold the headphone on/off button for 3 seconds, then the red and blue lights flash alternately to enter the pairing state
3. Turn on the Bluetooth listing and find "X7"
4. Click "X7" to connect (input password "0000" when necessary) and the Blue indicator will twinkle slowly.

Note: The pairing time of the Bluetooth headset is about 5 minutes at most. If the light is off, it means that the Bluetooth pairing state has stopped. If the pairing is still not successful, please retry above steps 1 to 4 to perform the pairing operation.

### Technical Specifications

#### Finished Product Parameters

- Bluetooth version: V5.0
- Main chip: Bluetrum
- Bluetooth profile: A2DP/HFP/SPP/HID/PBAP
- Bluetooth range: ≤10 meters
- Battery capacity: 80mAh
- Charging time: about 1 hour
- Standby time: 200 hours
- Talk time: about 10 hours
- Music playback time: 4-5 hours
- Speaker size: 14.2mm
- Frequency: 20Hz-20000Hz
- Impedance: 32Ω
- Sensitivity: 108±3dB
- Charging specification: DV5V
- Working voltage: 3.3V-4.2V
- Main material: Silicone + ABS

### warranty card

Product warranty instructions  
In order to better enjoy our services, please fill in the following details:

|                    |  |                     |     |
|--------------------|--|---------------------|-----|
| Product name       | model  | date of manufacture | / / |
| Production number  | Warranty period (including "Three Guarantees validity period") | 12 months           |     |
| Fuselage signature | User name  |                     |     |
| contact number     | postal address   |                     |     |

### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Warranty terms:

1. The goods are guaranteed for one year from the date of sale
2. The warranty service is valid only under normal use

3. All artificial damage, disassembled by user, improper use and other appearance damage are not within the scope of warranty. The warranty needs to provide this card. If the card is not provided or altered, the company has the right to cancel the warranty.

Note: the appearance of the product is subject to the real object. If there is any change in the technical specifications, please forgive me without notice