



C2 Bone Conduction Headphone



User Manual

Packing List




Package Contents:

- A. Bone Conduction Headphone x 1
- B. Earplugs x 2
- C. Type-C Charging Cable x 1
- D. User Manual x 1

⚠ If any questions are not answered in the manual, please check the product description on Amazon (FAQ at the product listing bottom), or contact our store customer service team through the Amazon platform, we will reply within 24 hours.


Product Overview




- 1 MFB Button
- 2 MFB Button
- 3 Indicator LED
- 4 Microphone
- 5 USB C Charging Port

Wear

1. As shown below, put the headphone around your neck with the speakers resting on the bone in front of your ears, not on your ears.




Note:
If you do not like being disturbed by external sounds when using the headphone, you can use it with earplugs(provided). The usage method is as follows:



Pairing

- Press and hold the MFB button on the right side of the headphone for **3 seconds** to power on, and the indicator flashes **blue-red** to wait to pair.
- Turn on your phone's Bluetooth, search for and click "C2".
- Pairing successful with a voice prompt "Connected".



Note:
a. After the headphone is disconnected from the phone, it will automatically enter the pairing state and shut down after 5 minutes.
b. When there is a pairing record, just power on, the headphone will automatically connect to the phone.


Power On

Press and hold the MFB button on the right side of the headphone for **3 seconds**. The headphone is powered on with the voice prompt "Power on". The indicator blinks blue for **2 seconds**.



Power Off


Press and hold the MFB button on the right side of the headphone for 5 seconds. The headphone is powered on with the voice prompt "Power Off ". The indicator blinks red for 2 seconds and then light off.




Note:
The MFB button on the left side of the headphone do not support the function of power on/off.

Phone Calls Control

Answer/End Calls: Press once the MFB button on the right/left side of the headphone.




Reject Calls: Press and hold the MFB button on the right/left side of the headphone for 2s.



Music


Play/Pause: Press once the MFB button on the right/left side of the headphone.




Next Track: Press and hold the MFB button on the right side of the headphone for 2s.



Previous Track: Press and hold the MFB button on the left side of the headphone for 2s.



Volume Up: Double press the MFB button on the right side of the headphone.




Volume Down: Double press the MFB button on the left side of the headphone.



Activate "Siri"

Triple press the MFB button on the right/left side of the headphone.


Press once the MFB button again to turn off "Siri" after activating.



Resetting


- In the state of power on without any device connected, quickly Triple press the MFB button on the right or left side of the headphone, and the earbuds will power off with the voice prompt "DI~ Power Off".
- Delete the bluetooth pairing record "C2" of the headphone on the mobile phone.

- After 10 seconds, Press and hold the MFB button on the right side of the headphone for 3s to power on, the indicator flashes blue-red to wait to pair.
- Turn on the phone's bluetooth to search "C2" and pair.



Charging

Use the Type-C charging cable(provided) to connect your computer (with power on) or an adapter(not provided) to the headphone. The indicator will stay red when charging and stay blue after fully charging.



Note:
The power level down to 3.3V starts to alarm, there will be a voice prompt " Battery is Low Please Charge" with the indicator flash red.

Specification

Model	C2
Version	V5.3
Transmission Distance	33 feet/10 meters (open space)
Supporting Protocols	HFP, A2DP, AVCTP, HSP, AVRCP
Impedance: 8Ω	8Ω
Battery Capacity	3.7V/140mAh
Talk/Music Time	About 5 Hours
Charging Time	2-2.5 Hours
Item Size	About 119.91*97.74*61.93mm
Item Weight	26.4g

Safety Instruction

- When using while walking, pay close attention to the surrounding traffic. It may cause a traffic accident.
- To protect your ears, do not turn up the volume too much.

- If the product drop into a flammable liquid such as water, please stop using it and contact us on Amazon. If you still continue to use it, it may cause a fire, malfunction, or electric shock.
- Opening the inside may cause a malfunction or electric shock. Do not touch the inside. In addition, we do not guarantee performance if the inside is modified by people.
- Do not charge it with wet hands or touch the charging port. It may cause electric shock.
- If you feel sick while using this product, please stop using it immediately.
- If you are using a medical device such as a pacemaker, consult your doctor before using it.
- Do not allow small children to use it.

Storage and Maintenance

- Store your headphones in a cool, dry place. Operating temperature 0~45°C(32~113°F). Working in a cold/hot loop mirror or in a highly humid place can reduce battery life. After storing it for a long time, please charge it before use.
- This BT headset is water resistant, but not completely waterproof. It can't be placed in water for a long time and cannot be used for diving. If there is water, wipe it off with a clean soft cloth.
- Clean the headphones with a soft, dry cloth.
- Do not touch any sharp objects to the headphones.
- Do not place the headphones under a very high or low-temperature ring mirror.

Q&A

- Q: My headphones don't turn on.
A: The battery level is low. Charge the headphones.
- Q: I cannot pair my headphones with my device.
A: Check whether the connected device supports Bluetooth, download or update the Bluetooth driver of the connected device
A: The Bluetooth is disabled. Enable the Bluetooth feature on your Bluetooth device and turn on the Bluetooth device before you turn on the headphones.
A: Resetting the headphone.
- Q: The device cannot find the headphones.
A: The headphones may be connected to a previously paired device. Turn off the connected device or move it out of range.
A: Resetting the headphone.
- Q: The audio quality is poor and crackling noise can be heard.
A: The device is out of range. Reduce the distance between your headphones and device, or remove obstacles between them.
A: Charge your headphones.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THANK YOU