


材质：80g 铜版纸  
印刷：单面黑字白底


## Storage Cable Wireless Charging Box

Instruction Manual  
#25177

### Product Overview



### Package Contents



- ① Type-C to Type-C data charging cable \* 1
- ② Type-C to USB A adapter \* 1
- ③ Type-C to Micro USB adapter \* 1
- ④ Type-C to Lightning adapter \* 1
- ⑤ SIM card ejector \* 1
- Storage Cable Wireless Charging Box \* 1
- Instruction manual \* 1

### Technical Specifications

Size	83*83*10mm
Material	ABS
Type-C input	5V=3A 9V=2A
Wireless output	5W/7.5W/10W/15W(max)
Color	White, Black

### Instructions

1. Ensure that your phone supports wireless charging.
2. Connect the wireless charging pad to the certified USB adapter using the charging cable provided.
3. Once the wireless charging pad is powered, the Indicator light will glow red 3times. And then Indicator light turn to green and steady on, means the wireless charger can work on.
4. When using wireless charging, the indicator light will glow red.

**Note:** In order to achieve the best charging performance, please use the cable provided or another certified cable with a current output exceeding 3A.

**Note:** If the indicator light is flashing red, it means the FOD technology (Foreign Object Detection) has detected an

unknown object between the wireless charging pad and the phone. (The wireless charging pad will not activate until this object has been removed.)

### Safety Precautions

**WARNING - When using this product, basic precautions should always be taken, including:**

1. Read all the instructions before using the product.
2. Do not overcharge your device. The unit may become hot from excessive use. Remove your device once it is fully charged. Never charge your device for longer than 7 hours.
3. To reduce the risk of injury, close supervision is required when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating.
6. Overloaded outputs above the rating may result in fire or injury.
7. Do not use the device if it has been damaged or modified.
8. Do not disassemble the device. Take the device to a qualified technician if service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Never store or use this product below 32°F (0°C) or above 113°F (45°C).
10. Have servicing performed by a qualified repair technician using only identical replacement parts.

### FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE 1:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE 2:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.



240 mm

80 mm

2023.06.15