

YORTOT

CLOCK-AC191 User Manual

New Version



Questions? Warranty ? Contact Customer Support at:
customer@kerweilai.com

SAVE THIS MANUAL FOR FUTURE REFERENCE

Thank you for purchasing YORTOT clock! To ensure the best possible product performance, please read this instructions in its entirety and retain it for future reference.


SPECIFICATIONS

TEMPERATURE RANGE	32°F to 122°F; 0°C to 50°C
POWER	9.18-ft.100-240V, 50/60HZ, 9W, Class 2
	2*AAA alkaline batteries (for backup; optional)

Features & Benefits




1. SET Button	8. 7 Color Night Lights
2. - Button	9. Night Light Dimmer
3. + Button	10. Daylight Saving Time
4. LED Dimmer	
5. 12/24H	
6. Indoor Temperature(C/F)	
7. Turn On/Off Night Light	



- 1. Clock
- 2. AM/PM Indicator
- 3. Indoor Temperature
- 4. Day of The Week
- 5. Date (month/day)



- 1. SET Button
- 2. 12/24H Button
- 3. Indoor Temperature Button(C/F)
- 4. LED Dimmer Button
- 5. 7 Color Night Light Button
- 6. Light Dimmer (Included Full Dark)



1. Integrated Hang Holes

2. Fold-Out Stand

3. Battery Compartment Cover

4. Battery Compartment

5. Power Adapter

1. Unpacking Instructions

Remove the protective film that is applied to the LED screen prior to using this product.

2. Install or Replace Backup Batteries

1. Remove the battery compartment cover.
2. Insert 2 x AAA alkaline batteries into the compartment, as shown.
3. Replace the battery cover.

Notice:

Batteries are a backup power source to preserve records in a case of power outage. And the screen will go blank.

Power adapter is required as the power source of this product.

3. Plug in Power Adapter

Plug the power adapter into a power outlet.



Remote Control

The CR2025 lithium battery has been included for power.

You can set clock by remote control.

4. Switch Time Format (12/24 hour)

Press 12/24H button to switch between 12 and 24 hour mode.

5. Set the DST & Time & Date

1. Press the “SET” button, located on the right of the clock, to enter SET MODE. Once in SET MODE the preference you are currently setting will blink on the clock.
2. To adjust the currently selected (flashing) item, press and release the “▲” or “▼” buttons (press and HOLD to fast adjust).
3. To save your adjustments, press the “SET” button to adjust the next preference. The preference set order is as follows:
 1. AUTO DST (ON or OFF)
 2. CLOCK HOUR
 3. CLOCK MINUTE
 4. YEAR
 5. MONTH
 6. DAY
4. You will automatically exit SET MODE if no buttons are pressed for 3 seconds.

Notice:

If you live in an area that observes daylight saving time, DST should be set to ON.

If you set the correct Year and the Date, the Day of week will automatically come up .Don't need to set the Day of week.

6. 5-Level Brightness of LED Display

Press the "LED Dimmer" button to adjust the display brightness, you can get your comfortable brightness for day/night. (Included Full Dark)

7. Switch Temperature (C/F)

Press the "F/C" button to switch between Celsius and Fahrenheit.

8. Switch the Color Night Light (7 colors)

Press the "NIGHT LIGHT" button to choose your favorite color night light at the bottom of the clock.

9. 4-Level of Brightness of the Night Light

Press the "LIGHT DIMMER" button to adjust the brightness, you can get your comfortable brightness. (Included Full Dark)

10. Care & Maintenance

Clock Care

Clean with a soft, damp cloth. Do not use caustic cleaners or abrasives. Keep away from dust, dirt and moisture. Clean ventilation ports regularly with a gentle puff of air.

11. SUPPORT (Any Questions?)

Please contact our friendly customer service team through support: customer@kerweilai.com, we will work hard to put a smile on your face within 24 hours 😊.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.