

User Manual V1.0

1. APP DOWNLOAD



Smart Life APP

iOS & Android

2. Instructions

1. Download and install the “Smart Life” or “Tuya Smart” APP from Google Play or App store,
2. Register and log in after installation.
3. Connect the USB smart gateway to the DC 5V power supply.
4. Confirm that the indicator light of distribution network (red light) flashes. If the indicator light is in other state, long press the "reset button" for more than 10 seconds until the light flashes. (Long press for 10 seconds, the LED red light will not flash immediately, because the gateway is in the process of resetting. Please wait patiently for up to 30 seconds)
5. Ensure that the mobile phone is connected to the family 2.4GHz band router. At this time, the mobile phone and the gateway are in the same LAN. Open the homepage of the APP and click the "+" button on the upper right corner of the page.
6. Click “Gateway Control” on the left of the page, then click “ Wireless Gateway (Zigbee)”
7. Operate the device to access the network Once added successfully, the device can be found on “My Home” interface.

Quality assurance

Under the normal use of users, the manufacturer provides free 2-year product quality warranty (except panel) replacement, and provides life time maintenance quality assurance beyond the 2-year warranty period.

The following conditions are not covered by the warranty:

Damage caused by external factors such as artificial damage or water inflow;

The user disassembles or refits the product by himself (excluding panel disassembly and assembly).

Beyond the technical parameters of this product Losses due to force majeure such as earthquake or fire.

Installation, wiring and use not in accordance with the manual.

Beyond the scope of the product's parameters and scenarios.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient un ou des émetteurs/récepteurs exempts de licence qui sont conformes au(x) RSS exempts de licence d'Innovation, Science et Développement économique Canada. Le fonctionnement est soumis aux deux conditions :

1. Cet appareil ne doit pas causer d'interférences.
2. Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement non désiré de l'appareil.

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with RSS-102 - Radio Frequency (RF) Exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Le dispositif de a été évalué à répondre général rf exposition exigence. Pour maintenir la conformité avec les directives d'exposition du RSS-102-Radio Fréquence (RF). ce matériel doit être installé et exploité à une distance minimale de 20 cm entre le radiateur et votre corps.