


Instruction Manual

Please read this manual carefully before use



①

5000mAh Battery Instructions



- 01.Power Button / Mode Selector. (Press and hold for about 2 seconds to turn the battery on/off; press once to adjust the temperature level.)
- 02.Battery Level Indicator: All 4 green lights illuminated indicate a full battery charge. Each of the 4 lights represents a portion of the remaining battery capacity.
- 03.Heating Mode Indicator: The 4 blue lights represent different heating modes, corresponding to Level 1 (Low), Level 2 (Medium), Level 3 (Medium-High), and Level 4 (High) temperature settings.
- 04.Type-C Charging Port: This is the port for charging the battery. Please use a power adapter rated at 5V/2A or higher.
- 05.

②

APP INSTALLATION AND USAGE INSTRUCTIONS




Step 1:
Scan the QR code on the left, or search for "DRCODC" in your phone's app store to install the application.
Download URL : <https://drcodc.com>




Step 2:
Turn on Bluetooth on your phone. (Simply ensure Bluetooth is enabled; no manual pairing or connection within Bluetooth settings is required.)

Step 3: Connect Device

- 1.
2. Open the app. Upon first launch, the app will request permissions to access your phone's Location Services and Bluetooth. Please grant these permissions. Connection will fail if you deny the permissions.




③





3.

After selection is complete, tap Connect in the top-right corner to connect.



4.

That Bluetooth is enabled on your phone.



④

PACKAGE CONTENTS

- 2 Battery Packs
- 1 Charging Cable
- 1 User Manual

IMPORTANT NOTES

1.Do not always use the highest heating setting. When you feel sufficiently warm, select a lower temperature setting to avoid burns. If you prefer not to use the app, you can also toggle between temperature levels directly using the buttons on the battery pack.

CLEANING INSTRUCTIONS

- 1.Water temperature must not exceed 50°C (122°F).
- 2.Remove the batteries before washing. Place the battery cables back into the battery storage bag. (Important: Batteries are NOT washable and must NEVER be submerged in water).

⑤

TROUBLESHOOTING & SERVICE

Note: In extremely low temperatures, the chemical activity of the lithium-ion battery may decrease, resulting in reduced usage time and potentially lower perceived heating levels. Device won't turn on? The battery may be low; please charge it. For any other unresolved issues, please contact us for service.

Disclaimer

- 1.Keep the product away from high temperatures, flammable materials, and explosive substances.
- 2.Do not subject the battery to strong impacts. Never disassemble or attempt to reassemble the battery.

SAFETY GUIDELINES

- 2.If the batteries are not used frequently, it is recommended to charge and activate them approximately every 60 days.

⑥

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.