





Test Graphs

Freq. Stability NVNT n40 5755MHz Ant1




Freq. Stability NVNT n40 5795MHz Ant1






Freq. Stability NVNT ac20 5745MHz Ant1




Freq. Stability NVNT ac20 5785MHz Ant1






Freq. Stability NVNT ac20 5825MHz Ant1




Freq. Stability NVNT ac40 5755MHz Ant1






Freq. Stability NVNT ac40 5795MHz Ant1



Freq. Stability NVNT ac80 5775MHz Ant1





Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	n40	5755	Ant2	5755	0	0	25	Pass
NVNT	n40	5795	Ant2	5795	0	0	25	Pass
NVNT	ac20	5745	Ant2	5744.98	-20000	-3.48	25	Pass
NVNT	ac20	5785	Ant2	5785	0	0	25	Pass
NVNT	ac20	5825	Ant2	5824.98	-20000	-3.43	25	Pass
NVNT	ac40	5755	Ant2	5755	0	0	25	Pass
NVNT	ac40	5795	Ant2	5794.96	-40000	-6.9	25	Pass
NVNT	ac80	5775	Ant2	5775	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen,
518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT n40 5755MHz Ant2




Freq. Stability NVNT n40 5795MHz Ant2






Freq. Stability NVNT ac20 5745MHz Ant2




Freq. Stability NVNT ac20 5785MHz Ant2






Freq. Stability NVNT ac20 5825MHz Ant2




Freq. Stability NVNT ac40 5755MHz Ant2






Freq. Stability NVNT ac40 5795MHz Ant2



Freq. Stability NVNT ac80 5775MHz Ant2



C.6 Duty Cycle



Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant1	94.56	0.24	0.91
NVNT	a	5785	Ant1	94.56	0.24	0.91
NVNT	a	5825	Ant1	94.65	0.24	0.91
NVNT	n20	5745	Ant1	93.77	0.28	1.07
NVNT	n20	5785	Ant1	93.77	0.28	1.07
NVNT	n20	5825	Ant1	93.77	0.28	1.07
NVNT	n40	5755	Ant1	97.18	0.12	0.46
NVNT	n40	5795	Ant1	97.23	0.12	0.46
NVNT	ac20	5745	Ant1	93.72	0.28	1.06
NVNT	ac20	5785	Ant1	93.72	0.28	1.06
NVNT	ac20	5825	Ant1	93.72	0.28	1.06
NVNT	ac40	5755	Ant1	97.19	0.12	0.46
NVNT	ac40	5795	Ant1	97.19	0.12	0.46
NVNT	ac80	5775	Ant1	94.32	0.25	0.97
NVNT	ax20	5745	Ant1	93.82	0.28	1.06
NVNT	ax20	5785	Ant1	93.72	0.28	1.06
NVNT	ax20	5825	Ant1	93.82	0.28	1.06
NVNT	ax40	5755	Ant1	97.19	0.12	0.46
NVNT	ax40	5795	Ant1	97.24	0.12	0.46
NVNT	ax80	5775	Ant1	94.32	0.25	0.97






Test Graphs

Duty Cycle NVNT a 5745MHz Ant1




Duty Cycle NVNT a 5785MHz Ant1






Duty Cycle NVNT a 5825MHz Ant1




Duty Cycle NVNT n20 5745MHz Ant1






Duty Cycle NVNT n20 5785MHz Ant1




Duty Cycle NVNT n20 5825MHz Ant1






Duty Cycle NVNT n40 5755MHz Ant1




Duty Cycle NVNT n40 5795MHz Ant1






Duty Cycle NVNT ac20 5745MHz Ant1




Duty Cycle NVNT ac20 5785MHz Ant1






Duty Cycle NVNT ac20 5825MHz Ant1




Duty Cycle NVNT ac40 5755MHz Ant1






Duty Cycle NVNT ac40 5795MHz Ant1




Duty Cycle NVNT ac80 5775MHz Ant1






Duty Cycle NVNT ax20 5745MHz Ant1




Duty Cycle NVNT ax20 5785MHz Ant1






Duty Cycle NVNT ax20 5825MHz Ant1




Duty Cycle NVNT ax40 5755MHz Ant1






Duty Cycle NVNT ax40 5795MHz Ant1



Duty Cycle NVNT ax80 5775MHz Ant1






Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant2	94.56	0.24	0.91
NVNT	a	5785	Ant2	94.56	0.24	0.91
NVNT	a	5825	Ant2	94.65	0.24	0.91
NVNT	n20	5745	Ant2	93.67	0.28	1.07
NVNT	n20	5785	Ant2	93.67	0.28	1.07
NVNT	n20	5825	Ant2	93.67	0.28	1.07
NVNT	n40	5755	Ant2	97.23	0.12	0.46
NVNT	n40	5795	Ant2	97.18	0.12	0.46
NVNT	ac20	5745	Ant2	93.82	0.28	1.06
NVNT	ac20	5785	Ant2	93.72	0.28	1.06
NVNT	ac20	5825	Ant2	93.72	0.28	1.06
NVNT	ac40	5755	Ant2	97.19	0.12	0.46
NVNT	ac40	5795	Ant2	97.24	0.12	0.46
NVNT	ac80	5775	Ant2	94.41	0.25	0.97
NVNT	ax20	5745	Ant2	93.72	0.28	1.06
NVNT	ax20	5785	Ant2	93.82	0.28	1.06
NVNT	ax20	5825	Ant2	93.72	0.28	1.06
NVNT	ax40	5755	Ant2	97.19	0.12	0.46
NVNT	ax40	5795	Ant2	97.19	0.12	0.46
NVNT	ax80	5775	Ant2	94.41	0.25	0.97






Test Graphs

Duty Cycle NVNT a 5745MHz Ant2




Duty Cycle NVNT a 5785MHz Ant2






Duty Cycle NVNT a 5825MHz Ant2




Duty Cycle NVNT n20 5745MHz Ant2






Duty Cycle NVNT n20 5785MHz Ant2




Duty Cycle NVNT n20 5825MHz Ant2






Duty Cycle NVNT n40 5755MHz Ant2




Duty Cycle NVNT n40 5795MHz Ant2






Duty Cycle NVNT ac20 5745MHz Ant2




Duty Cycle NVNT ac20 5785MHz Ant2






Duty Cycle NVNT ac20 5825MHz Ant2




Duty Cycle NVNT ac40 5755MHz Ant2






Duty Cycle NVNT ac40 5795MHz Ant2




Duty Cycle NVNT ac80 5775MHz Ant2







Duty Cycle NVNT ax20 5745MHz Ant2




Duty Cycle NVNT ax20 5785MHz Ant2




Duty Cycle NVNT ax20 5825MHz Ant2



Duty Cycle NVNT ax40 5755MHz Ant2



Duty Cycle NVNT ax40 5795MHz Ant2



Duty Cycle NVNT ax80 5775MHz Ant2

