



SIDE 1

<div><div>MXH-BT800</div><div></div><div>Bluetooth® WIRELESS HEADSET</div></div>		<div><div>BLUETOOTH SPEAKER MXH-BT800</div><div>Thank you for choosing our product. This product was created, according to local regulation, by our professional team. For best use of your new device we recommend carefully reading the user manual and keeping it for your records.</div><div>RANGE OF USE</div><div><ul style="list-style-type: none">• In compliance with Bluetooth enabled devices• Music listening (mobile device, PC, or internet)• Answer calls wirelessly• Web chat (supports ICQ, MSN, Skype, etc.)• Pair with PC (Bluetooth connection or USB cord for headset)• Line In</div><div>Package contains: - MXH-BT800 Bluetooth wireless headset - USB charging cord - 3.5mm audio cord - Instruction manual</div></div>	<div><div>CONTROLS - SIDE VIEW</div><div></div><div>1. Previous Song/ Volume up 2. Next Song/ Volume Down 3. Play/Pause/Mute 4. ON/OFF, Pairing, Answer/Reject Call, Redial</div></div>	<div><div>CHARGING</div><div>This product comes with an uncharged built-in rechargeable battery. Before using for the first time charge for at least 4 hours. After first charge, headset will take approximately 2-3 hours. LED light turns red when charging and LED light turns blue when charging is complete.</div><div>PAIRING YOUR BLUETOOTH DEVICE</div><div>1. Press and hold Power button on headset for about 5 seconds. Let go of button when LED alternately flashes red and blue, when headset is in pairing mode. 2. Turn on your Bluetooth enabled device, search for "MXH-BT800" in your Bluetooth device search list, then pair your Bluetooth device with the headset (headset name cannot be searched if it is not set to pairing mode). If your Bluetooth device asks for a password, input "0000". If headset does not pair with a device within 3 minutes, it will automatically turn itself off. 3. Headset when device is paired and LED with slowly flash blue once every 2 seconds. 4. Both the headset and your Bluetooth enabled device will store the other device's name. Next time you use the same Bluetooth device to connect to the headset, no password will be needed.</div></div>	<div><div>POWERING ON/OFF & RECONNECTING</div><div>POWER ON (RECONNECTING TO DEVICE) Press and hold the Power button for about 1 second to turn on headset. LED light will quickly flash about twice a second, and headset will automatically connect with last paired device. Once reconnected, and LED light will slowly flash blue about once every 2 seconds. NOTE: Headset will only reconnect with last paired device. If headset does not pair with either last paired device or a new device headset will automatically turn itself off. POWER OFF Press and hold Power button for about 3 seconds. LED will flash purple for 1 second then headset. Headset will then turn itself off.</div></div>	<div><div>PLAYING AUDIO WIRELESSLY</div><div>NOTE: paired device should support Bluetooth A2DP profile 1. Follow the "PAIRING YOUR BLUETOOTH DEVICE" instructions in this manual. Once your the headset is paired with your device you can now enjoy listening to audio through the headset. 2. To skip to the next song press the Next Song button once. To play previously played song press the Previous Song button once. 3. To play or pause press the Play/Pause button once. 4. To lower volume press and hold the Previous Song button. To raise volume press and hold the Next Song button. 5. To pick up an incoming call (and pause audio) press the Power button. After ending a call, audio will resume automatically. LINE IN If a Bluetooth enabled device is unavailable, or battery is depleted, plug the included 3.5mm audio cord into the LINE IN jack. Headset will function as a wired headset until audio cord is unplugged. LOW BATTERY INDICATION When headset battery is low, the LED light will flash red and emit a beep twice every 10 seconds until headset shuts down. Recharge.</div></div>	<div><div>MAKING CALLS</div><div>1. Follow the "PAIRING YOUR BLUETOOTH DEVICE" instructions in this manual. Once your the headset is paired with your mobile phone you can now control calls through the headset. 2. DIALING AND REDIALING -Dialing: Use your mobile phone to dial a number as usual. You will hear a voice after dialing. The call will then be connected and will automatically switch to the paired headset. (Some mobile phones may need to be switched manually). -Redialing: Press the Power button once on the headset to redial the last number dialed. 3. ANSWERING AND ENDING A CALL -When receiving an incoming call you will hear a voice through the headset. Press the Power button to answer the call. -During an active call press Play/Pause on the headset to transfer call to the paired mobile device. Press the Play/Pause button again to transfer the call back to the headset (some mobile phones may not support this feature). -To reject an incoming call, press and hold the Power button for about 1 second. -To lower call volume press and hold the Previous Song button. To raise call volume press and hold the Next Song button. -To end a call press the Power button once.</div></div>
---	--	--	--	---	---	---	--

SIDE 2

<div><div>CAUTION:</div><div><ul style="list-style-type: none">• Do not use abrasive cleaners to clean your speaker. It could cause scratches and damage.• Do not bring your speaker in to contact with any sharp objects. It could cause scratches and damage.• Do not insert anything into your speaker unless otherwise specified in the user instructions. This may damage the internal components.• Do not attempt to repair, modify, or disassemble your speaker yourself, it does not contain any user-serviceable components.• Do not attempt to replace your speaker battery, it is built-in and is not changeable.• Use only the manufacturer supplied charger to charge your speaker. Other chargers may look similar, but using them could result in electric shock and could damage.• Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.• Turn off your speaker prior to boarding an aircraft. Do not use the speaker inside an aircraft unless allowed by your airline.• Dispose of the speaker and its battery in accordance with local regulations. Do not dispose of the battery with regular household waste.</div></div>	<div><div>PRODUCT MAINTENANCE</div><div>-Using non-original accessories may cause performance degradation, voided warranty, electrical short circuit, and/or personal injury. -Disassembly can cause damage your headset and void warranty. -Do not place headset in a dusty environment. -Use a clean, soft, dry cloth to clean headset. -When not in use fold product and put in sack to preserve. -Keep headset away from children. -Avoid using headset in extremem temperatures. BATTERY MAINTENANCE -Send headset to qualified repair center to remove or replace battery. -With proper use, headset battery life can be extended. -Battery works at temperatures between 50° - 113° F (10° - 45° C). -Battery capacity can be fully utilized at room temperature. In outdoor conditions, battery capacity may decrease. -If headset is not in use for an extended period, charge battery at least once every two months.</div></div>	<div><div>FIRE AND ELECTRIC SHOCK HAZARD</div><div><ul style="list-style-type: none">• Do not expose your Bluetooth Wireless Speaker to liquid, moisture, humidity, or rain. Do not use the speaker near a bathtub, sink, sauna, pool, or steam room. Exposure of the speaker to moisture could result in electric shock.• Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the Bluetooth Wireless Speaker. Such actions could result in electric shock.• Clean the Bluetooth Wireless Speaker only with a dry cloth.• Do not expose your Bluetooth Wireless Speaker to extremely high or low temperatures.• Do not leave your Bluetooth Wireless Speaker in direct sunlight for extended periods of time.• Do not leave your Bluetooth Wireless Speaker near open flames such as cooking burners, candles, or fireplaces.• Do not block any ventilation openings.</div><div>FALL HAZARD</div><div><ul style="list-style-type: none">• Do not place the Bluetooth Wireless Speaker on high surfaces such as shelves. During music playback the Bluetooth Wireless Speaker may move which could cause the speaker to shift and fall off of the edge.</div></div>	<div><div>FCC Statement:</div><div>This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to this equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the radio or television off and on, the user is encouraged to try to correct interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on another circuit. - Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. Industry Canada Statement: This device complies with RSS-210 of the Industry Canada Rules.</div></div>	<div><div>Operatonis subject to the following two conditions: 1) this device may not cause interference and 2) this device must accept any interference, including interference that may cause undesired operation of the device. IC Radiation Exposure Statement: This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. Avis d'Industrie Canada: Cet appareil est conforme à la norme CNR-210 des règlements d'Industrie Canada. Son fonctionnement est sujet aux deux conditions suivantes: 1) Cet appareil ne doit pas provoquer d'interférences et 2) Cet appareil doit accepter toutes les interférences, y compris celles pouvant entraîner son dysfonctionnement. Avis d'Industrie Canada sur l'exposition aux Rayonnements: Cet appareil est conforme aux limites d'exposition aux rayonnements d'Industrie Canada pour un environnement non contrôlé. Industry Canada Statement: This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: 1) this device may not cause interference</div></div>	<div><div>and 2) this device must accept any interference, including interference that may cause undesired operation of the device. This class B digital apparatus complies with Canadian ICES-003 IC Radiation Exposure Statement: This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. Avis d'Industrie Canada: Cet appareil est conforme à la norme CNR-210 des règlements d'Industrie Canada. Son fonctionnement est sujet aux deux conditions suivantes: 1) Cet appareil ne doit pas provoquer d'interférences et 2) Cet appareil doit accepter toutes les interférences, y compris celles pouvant entraîner son dysfonctionnement. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada Avis d'Industrie Canada sur l'exposition aux Rayonnements: Cet appareil est conforme aux limites d'exposition aux rayonnements d'Industrie Canada pour un environnement non contrôlé.</div></div>
---	--	--	--	---	--