

SETTING UP THE TRANSMITTER



The 1/4" LINE-IN jack **1** on the rear of the transmitter enables you to connect directly from an audio source such as a tape player.

MICROPHONE INPUT the 1/4" jack **2** on the back panel is designed to accept either dynamic or electret microphones.

POWERING THE TRANSMITTER

- Connect the AC adapter provided into the 12V DC jack **3** on the back panel of the transmitter. Plug the other end into an AC wall socket.
- Press power switch **4** on, the power on LED **5** will show power is getting to the system.

The transmitter's "signal" LED **6** will illuminate to confirm that the transmitter is broadcasting.



ALS-600BP RECEIVER Features & Controls

- Volume control
- LED Power On/Battery indicator
- Power On/Off Switch
- Earphone Jack

Powering The Receiver

Install a 9V battery in battery compartment **10** on the back of the receiver.


Observe polarity. To preserve battery life, always turn ALS-600BP receiver off when not in use. When the Power On/Battery LED **8** turns red or sound becomes weak or distorted, replace battery. The life expectancy from an alkaline battery is 17-20 hours.

Operating the Receiver

Plug the included ALS-600EB earphones **11** into the earphone jack **10** on top of the receiver. While wearing your earphones, stand near the ALS-600 transmitter. Turn on the receiver with the power on switch **9** and the LED indicator **8** will be visible.

Listen for your program source and adjust the volume control **7** for a comfortable listening level. If no sound is heard adjust the volume level **8** on the transmitter.

NOTE: You may wish to dispose of the foam ear pads after use or they can be re-used after being washed in mild detergent, rinsed and air-dried. The foam earpads can be ordered separately.



Note: The device has has no ad-hoc function.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes and modifications to this equipment. Such changes and modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct eth interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.