


FEATURES



A-Control Panel

A1-Power On/Off Button Switch and Volume Adjustment

A2-Bass Volume Adjustment

A3-Treble Adjustment

A4-Headphone Plug in Jack

A5-Audio Input for Linking Futon

A6-9V DC Power Input Jack

A7-SD CARD

A8-USB IP/Charging

A9-Power Indicator Light

A10-Short press for play/pause

A11-Short Press for Prev

A12- Short Press for Next

B-Accessories Supplied

B1-1.5m 3.5mm Stereo to 3.5mm stereo plug cable(1 PC)

B2-INPUT:100-240V AC 50/60Hz

OUTPUT:9V DC 1.5A 13.5W Main POWER Adapter

C-Audio Specification

Signal-to-Noise Rate(Amplifier):Subwoofer:>65db


Satellite: >60db

Frequency Response:30HZ~20KHZ

Distortion:Subwoofer:<1%(F=100HZ)

Satellite:<1%(F=1KHZ)

Input:DC 9V/1.5A



step:

1: Unpack the power adapter DC9V/1.5A and connect it to the main power outlet, then to the power jack on the control panel.(A6)

2: Start by rotating clockwise, confirm the Bluetooth light on, connecting by phone in pass code:0000

3: Both SD/U and Audio can be stand by plug in,(red in Audio model; red flashing in SD/U model)

4: Short press Play/Pause for play and pause; press 2 seconds change into Bluetooth/SD/U/Audio

5: Short press for prev, long press for volume down(only work on Bluetooth and SD/U)

6: Short press for next, long press for volume rise(only work on Bluetooth and SD/U)

7: VOLUME: Power on/off button switch and volume adjustment

8: BASS: bass volume adjustment

9: TREBLE:Treble adjustment

10: Headphone: Headphone plug in jack

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.