


A10G mouse user guide


1 Open the battery cover.



3 Close the battery cover.



5 Open the battery cover on the back of keyboard. Insert one A AA battery as the diagram on the battery tray indicates. Close the battery cover.



2 Insert one AA battery as the diagram On the battery tray indicates.



4 Switch the On/Off button to On, the LED2 indicator will light in red.



6 Plug the USB receiver into an available USB port on your computer. Press any key to start.



Set Wireless Connection

The mouse is pre-paired before packing. Users can use the wireless mouse after installing the battery.

1. Turn on the computer.
2. Plug the USB receiver into an available USB port on your computer.
3. Install 1*AA battery into the mouse. Press any key to start.

Mouse Feature

Install driver for more features

Download and install the driver, define the tilt wheel, you can enjoy more features, and there's battery power icon in the taskbar to indicate the current power consumption.




Energy-saving mode

The mouse is with energy saving mode, when you stop using it for 0.2s, it will automatically switch into the energy-saving mode, which can extend the battery life.

DPI Switch


The mouse has 1000/1500/2000 of DPI for your choice freely. The factory default is 1000DPI. You can choose the DPI you like by pressing the DPI key, the LED will flash different times according to the different DPI.

DPI value	LED flash
1000dpi	LED 3 flash green light 3 times
1500dpi	LED2+LED3 flash green light 3 times
2000dpi	LED1+LED2+LED3 flash green light 3 times




Side Buttons Feature

The mouse is with 2 side buttons. For Windows2000 or above, the buttons are defaulted as browser forward and backward buttons. For further function, please download from www.fuhlenstyle.com for your self-definition.



Receiver Build-in design

The mouse is with nano receiver build-in design, when you stop using the mini USB receiver, it can be stowed away in a hidden compartment inside the mouse. It is more convenient for storing.




Low power indicator

The mouse has low power indicator, when the power is nearly used up, the LED2 will flash in red to remind you to replace the battery.


LED2 is DPI switchable and low power indicator.

After the power is completely used out, the LED will be off, so please replace the battery in time.



On/Off switch

On the bottom of the mouse, there is a On/Off switch. When you are traveling or on a plane or stop using it for a long time, please switch it to Off to save power.



Technical data

Frequency band: 2402MHz ~ 2479MHz

Power supply: 1.5V

Mouse operating current: $\leq 6\text{mA}$

Acceleration: up to 20G

Resolution: DPI 1000/1500/2000 switchable

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.