GT-3842 EN ES



Accordina to the operatina of your mobile, scan the following QR code to download and install.





Android



1. Introduction

Congratulations on your purchase of a Smart. Wireless Bluetoothconnected Cookina





-02-

S button

Thermometer: TempSpike. You will now be able to remotely monitor the

2. Features

1. Booster: Receives the tempera - ture signal from the probe and and transmits it to the smart device. It also serves as a power source to charge the probe.

2. Probe: Inserted into meat and measures the internal temperature and ambient temperature,

waterproof. Probe Battery Power Indicator: When it flashes quickly, it indicates the probe

battery power is low and needs to be recharged

When the probe is being charged, the light will flash slowly. After the probe is fully charged, the light will be off.

4. Booster Battery Power Indicator: When it flashes

quickly, this indicates the booster battery power is low and needs to be recharged. When the booster is being

enough so that the meat will

cover this notch. 7. S button: Serves 3 functions: Press once to silence the booster's alarm when the meat temperature reaches the target temperature;

Press and hold for 3 seconds to pair the booster and the probe; Press and hold for 10

seconds to reset the

booster.

8. USB Charging Port (Type C)

9. Sensors: Dual temperature sensors can monitor internal meat temperature up to 212°F (100°C) and ambient temperature up to 572°F(300°C)

magnets allow

any other metal surface.

simultane - ously. 10. Magnet: Two strong built-in you to attach the booster onto your grill,

Scan the QR code above,

or search for "TempSpike" on the Apple Store for iOS devices or on the Google Play Store for Android devices. Download the App and install it on your smart device.

Step 2: Enable Bluetooth on your smart device under the Settings section. If your smart device already has Bluetooth enabled, you can skip this step.

Step 3: Fully charge the booster and the probe

Connect the USB charging cable provided to any USB charger to charge the booster. The booster battery indicator light wil

turn off once it is fully charged. Place the probe in the booster to charge the probe. The probe battery indicator light will turn off once the probe i

2) Press and hold the S button until you see the Connection Indicator begin to flash green quickly;

3) Wait for a few seconds

until the Connection

Indicator begins to flash green slowly. Once this occurs, this means the probe and the booster are successfully paired Once they are paired, you do not need to pair them again for future uses.

Step 5: Pair the booster to your smart device

1) Remove the probe from the booster;

2) Launch the TempSpike App and press Add Device. A list of TempSpike devices will appear and select TempSpike from the list. The App will jump to device list page which shows the real time temperature

measured by the probe.

Now your TempSpike is

ready for use. You don't

need to pair them again

reaches your target temperature, an alarm will sound from the App

and the booster. Caution

> 1. There are sophisticated and delicate electronics within the probe. To avoid extremely high heat which could damage the electronics, please ensure to always insert the probe deeply enough into the meat so that the notch on the probe is fully covered by the meat.

2. Do NOT use TempSpike in the microwave.

3. The connection range between the probe and the booster usually can go as far as 160 feet (50 meters) in an open area, it can be dramatically reduced to as short as 10 feet (3 meters) when the probe is inserted

the probe from the meat you finish cooking.

responsible for compliance

could void the user's

operate the equipment.

NOTE: This equipment

has been tested and

found to comply with

the limits for a Class B

pursuant to Part 15 of

provide reasonable

protection against

interference in a

installation. This

the FCC rules. These limits

device,

designed to

authority to

digital

harmful

residential

equipment

5. Use a kitchen towel or rag to wipe and clean the probe after each use. Rinse the probe when it get back to normal

temperature, please DO NOT rinse the probe when the temperature is still high, it may damage the device. 6. After cleaning the always

place the probe in the

booster for charging and

* WARNING FOR ARTIFICIAL CARDIAC PACEMAKER USERS Please be aware that a magnet installed inside the device may impact the functionality of your artificial cardiac pacemaker. If you have a pacemaker, we

generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. recommend always However, there is no staying up to 1 foot or guarantee that 0.3 meter away from interference will not the device. occur in a particular

6. Declaration of Conformity

Hereby, the manufacturer declares that this product with the basic requirements and applicable regulations of the Radio Equipment Directive 2014/53/EU, the EMC Directive 2014/

30/EU The complete declaration of conformity oan be found at: tronicsmall.com/ eu-dec-laration-of-

7. Disposal of the Electronic Appliance

This electronic appliance should not be disposed o with normal household waste. Dispose of the

at an approved facility or

at your local recycling

to TempSpike.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

7797

conformity/complies

(USA & Canada only) 33-975

15570 (IT) 34-

(ES) 44-808-

164-1683 (UK)

61-180-057-

8:00PM EST (USA &

* The stated transmission range is based on tests at an

Temperature Range

Internal

Ambient

Temperature

Temperature

Sensor Tupe

Temp Tolerance

Transmission Range *

Booster to Smart

device

Probe

Booster

Wireless

Technologi

Unit Size:

Probe

Booster

Power:

Probe

Booster

Battery life:

Call or Text: 1-877-515-

052-317-

910-601-787

Canada only)

9. Customer Service

-129-576 (FR)

49-215-493-

19011 (DE) 39-

7492 (AU)

service@buythermopro.com

Hours: Weekdays 8:00AM

temperature of 77°F or 25°C

without any obstructions or electromagnetic interference.

ф = Diameter x 5 = Length inches

(170.0L x 47.0W x 27H mm)

 $6^{\frac{3}{2}}$ Length x 1 $\frac{1}{8}$ Width x 1 Height inches

2.4V (Built-in lithium rechargeable battery)

3.7V (Built-in lithium rechargeable battery)

Specifi cation

otherwise ±2%

oven/grill style

500ft(150M)

36 hours or more

3 months or more

(\$6.5D x 132L mm)

Bluetooth 5.2

Probe to Booster | 6.5Ft ~ 33Ft (2m~10m) depending on the

14°F to 212°F (-10°C to100°C)

14°F to 572°F (-10°C to 300°C)

±1.8°F (±1.0°C) from 14 to 212°F (-10 to

Your range can vary depending on the number of







internal food temperature and ambient temperature and how much time is left for the food to be done from your smart device.

-01-

charged, the light will flash slowly. Once the booster is fully charged the light will be off.

> 5. Connection Indicator: If probe and the booster are connected, the indicator will flash green slowly. If the probe loses connection with the booster, it will flash red slowly. When the probe is placed in the booster for charging and storage, the light will be off.

6. Notch: When the probe inserted into meat for measuring the meat's internal temperature, the probe

3. Components

4. Usage

Follow the simple steps below to set up your TempSpike and help you Cook Like a Pro!

install the "TempSpike" Арр.

must be inserted deep

-03-

1 x Manual

Step 1: Download and

-04-

1 x Probe

1 x Booster 1 x USB Charging Cable

The booster and the probe are pre-paired via Bluetooth at our manufacturing facility. Removing the probe from the booster, you will see

Step 4: Pair the probe to the

fully charged.

the Connection Indicator begin to flash green slowly, this indicates that the booster and

If for any reason you need to re-pair them or you have a new probe or a booster to be paired, please follow the below steps:

probe are paired.

1) Remove the probe from the

for future uses.

Step 6: Start Cooking

1) Insert your probe into the meat deeply enough so that the notch on the probe is fully covered by the meat; 2) Set your desired meat

temperature or select the meat type and doneness you desire within the TempSpike App and/or set the highest/lowest ambient temperatures you prefer;

3) Once the target temperature

-06-

probe until the Connection Indicator light

4. Always wear glove to

remove -07-

into the meat and

then the metal cooking

Therefore, we strongly

booster as close as possible

to the probe when it is

inserted in the meat,

such as resting directly

appliance and always

pay attention whether the

Connection Indicator light

flashes red which indicates

the connection between

the probe and the

booster is lost. When this

occurs, please move the

booster closer to the

flashes green again.

outside the cooking

appliance is closed.

suggest placing the

5. FCC

Statement of Compliance

modifications to this

unit not expressly

approved by the party

This device complies with Part 15 of the FCC rules. Operation is to the following two conditions: 1) This device may not cause harmful interference, and 2) This device must accept any interference

received, including - Increase the separation interference that may between the equipment and the receiver. undesired operation. - Connect the Warning: Changes or

installation. If this does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures: - Reorient or relocate the

equipment

receiving antenna.

equipment into an outlet on a circuit different

from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

center. Please observe the current rules regulations when disposing of the appliance. Contact your council if in doubt.

8. Limited One-Year Warranty

TempSpike warrants this product to be free of defects in parts, materials and workmanship for a period of one year, from date of purchase.

Should any repairs or servicing under this warranty be required, contact Customer Service phone or email for instructions on how to pack and ship the product

-10-

-12-

-11-

-1FCC Statement

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

Reorient or relocate the receiving antenna.

interference by one or more of the following measures:

obstructions and electromagnetic in your environment.

Increase the separation between the equipment and receiver.

radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

This equipment has been tested and found to comply with the limits for a

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-09-

		-	