Bluetooth wireless speaker

USER MANUAL




Please read this user manual carefully before use

V4.2
5W (RMS)
IPX7
Built-in 850mAh rechargeable Li-on Polymer battery
DC 5V/IA
115Hz-15KHz
≤30M (Opening Filed)
4Ω5W/50mm
Micro USB port
Up to 10 hours
3 hours

Accessories: 1pcs USB cable 1pcs User manual

1 ILLUSTRATION



Power ON/OFF:

- 1. Hold on Multi-function button for 3 seconds to turn speaker on/off
- 2. Short press can switch to Micro SD card mode
- 3. When the device is malfunction, hold more than 6 seconds, speaker will reset
- 4. Double click to entry TWS mode or cancel TWS connection (TWS version only)

Use the product as directed. This unit has been designed

and manufactured to ensure your personal safety, however

improper use can result in potential electrical shock or fire

hazards. Please read all safety and operating instructions

1. The unit should be stored and used under room temperature environment.

4. The unit should not be disassembled or repaired by an unauthorized person.

5. The built-in Li-ion battery should not be thrown into the fire or any other place

6. The unit should be serviced and repaired by the qualified personnel when it is

7. Please charge in time, or it will affect the headphone connection when battery

2. The unit should not be used under water and in a humid environment.

3. The unit should not be thrown as it could result in damage.

V+ and V- key:

- 1.V+: a.) Hold on for 2 seconds to previous track
 - b.) Press to increase the volume
- 2.V-: a.) Hold on for 2 seconds to next track

carefully before installation.

to avoid hazards.

b.) Press to decrease the volume

-Charging Port -Micro SD Card Slot

Micro SD Card Slot:

1. Place micro SD card into the slot, Audiofiles will start playing automatically.

1. Connect the micro USB side of the supplied cable to the charging port of the speaker, and the USB side to any USB charger or computer USB port. The speaker indicates charging mode by red LED, when the speaker is fully charged the LED turns off automatically.

2 OPERATING GUIDE

Play and Pause Key:

- 1. Play and pause music
- 2. Call waiting-click to answer the call
- 3. While answering the call-click to hang up the call
- 4. During in coming call-hold it will reject the call
- 5. When mobile connected speaker, double-click to call back the last call
- 6. Hold it more than 2 seconds will disconnect the speaker while bluetooth playing

Bluetooth Pairing:

1.Turn ON speaker the indicator flash in blue and waiting for device connection 2.Go to the Bluetooth settings in your device, find T101 and choose to connect, when the pairing is successfull sound is played from the speaker and the indicator turn in blue steady.

Charging:

- 1. Turn off the speaker before charging
- 2. Connect the speaker with micro USB cable
- 3. The indicator flash in red when speaker is low battery

3 SPECIFICATIONS

SPECIFICATIONS

Bluetooth Version	V4.2
Rated Power	5W (RMS)
Waterproof	IPX7
Battery Capacity	Built-in 850mAh rechargeable Li-on Polymer battery
Power Supply	DC 5V/IA
Frequency Response	115Hz-15KHz
Receiving Range	≤30M (Opening Filed)
Driver Unit	4Ω5W/50mm
Charging Port	Micro USB port
Playing Time	Up to 10 hours

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.