



GYMWATCH
Sensor

Copyright © 2014 GYMWATCH

User manual

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation

Section 15.21 Information to user

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

Section 15.105 (b)

Note:

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

IC (INDUSTRY CANADA) STATEMENT

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:


- (1) L'appareil ne doit pas produire de brouillage.
- (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



FCC ID: 2AC6J-GW1000
IC: 12332A-GW1000

GYMWATCH GmbH, Goebelstrasse 21, 64293 Darmstadt, Germany

www.GYMWATCH.com



In order to use your **GYMWATCH® Sensor** with a mobile device, please install the **GYMWATCH® App** on your smartphone or tablet.


Search for “**GYMWATCH® App**” and download it from Google Play or from the iOS App Store.

For more information visit www.GYMWATCH.com!

PRODUCT VIEW

Smart Light

Colored LED, that gives you feedback on your input and the sensor status




Armband Loop

That's where your armband leads through

Micro-USB Slot


Protected micro-USB slot for charging the battery.



Sensor Button



Your multifunctional control element, you use to navigate through your training.

CONTENT OF THE PACKAGE



One **GYMWATCH® Sensor** with a **short armband** to be mounted to your upper- and forearms.


One **Micro-USB** cable for a quick recharge of the powerful battery.



One **long armband** to mount the sensor to your upper and lower legs, such as arms with higher girth.

CHARGE THE BATTERY

The battery of your GYMWATCH® Sensor can easily be charged via Micro USB cable, which is inside the package.



i Unplug the USB slot of your sensor and connect the Micro-USB cable with your device. Connect the other end of the wire with another USB device or a power outlet with USB connection. Make sure you have the device in range of your sensor and the charger is compatible with the hardware of your GYMWATCH® Sensor.