Wireless Adapter

Operation Manual



HOW TO USE IT?



Features

■ Worldwide 2.4GHz ISM Band

■ Output Accuracy: C.W.:±1%;C.C.W.:±1.5%

■ Display: 5 Digits LCD

■ Temp. Range-Operating : -5°C to +55°C■ Temp. Range-Storage : -20°C to +70°C

■ RS-232 Data out / Optional

■ N-m, Kg-m, Ft-Lb, In-Lb are interchangeable

■ Mode : Track, Auto reset (See Tolerance setting page)

■ Directions : C.W., C.C.W.

■ Memory : 20 Readings

■ Humidity: 0-90%

■ Battery (Receiver): 1.5V UM-3(AA)X3, (Do not use low-discharge battery)

■ Battery (Transmitter): 1.5V UM-4(AAA)X3, (Do not use low-discharge battery)

Model	Range
WET-500N	50.0 ~ 500.0 Nm
WET-1000N	* 100.0 ~ 1000.0 Nm
WET-1500N	150.0 ~ 1500.0 Nm
WET-2000N	* 200.0 ~ 2000.0 Nm

CE F©

* Finished Edition 01

Check Your Parts





Transducer (Transmitter)



Monitor (Receiver)

Fuction






18 17

- (1) Receiver Power switch / Backlight switch
- (2) Down / Decrease
- (3) Up / Increase
- 4 Set
- (5) Memory
- (6) Zero / Quit /Confirm
- (7) Buzzer / Beep sound
- (8) Data out / RS232 / Optional
- (9) LED-Green
- (10) LED-Yellow
- (11) LED-Red
- 12 LCD-Display
- (13) Aux. / Reserved
- 14) Receiver Battery Box / AA X 3
- (15) Stander
- 16 Transmitter Battery Box / AAAX 3
- (17) Transmitter Power switch
- (18) Status LED

Display



Icon Meaning











Beep Sound


Press the Button 1 Time Press the Button 1 Sec. LCD Blinking












Power OFF Work mode Backlight ON Backlight OFF

LED Light

Power

















Zero






Pre-set

Working Diagram



20 sets of historical

RS-232 (Optional)



Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.