



BT-250ANC Bluetooth® Wireless Over Ear Headphones with Active Noise Cancelling (ANC)



P/N 43550

User's Manual

SAFETY WARNINGS AND GUIDELINES

Please read this entire manual before using this device, paying extra attention to these safety warnings and guidelines. Please keep this manual in a safe place for future reference.

- This device is intended for indoor use only.
- Do not expose this device to water or moisture of any kind. Do not place drinks or other containers with moisture on or near the device. If moisture does get in or on the device, immediately remove it from its power source and allow it to fully dry before reapplying power.
- Do not expose this device to excessive vibration or extreme force, shock, or fluctuations in temperature or humidity.
- Do not use these headphones while operating a motor vehicle or heavy equipment, walking in traffic, or any other situation in which situational awareness is a key to safety.
- Avoid prolonged exposure to excessive volume levels, which could cause hearing damage. Reduce the volume to minimum before wearing these headphones, then increase the volume to a comfortable listening level.
- Do not expose this device to excessively high temperatures. Do not place it in, on, or near a heat source, such as a fireplace, stove, radiator, etc. Do not leave it in direct sunlight.
- This device contains a Lithium battery. Dispose of this device only in accordance with local, state, or federal regulations for electronic waste.

- Charge the battery before first use and at least once every three months to keep it fresh and capable of holding the full charge.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user serviceable parts. Do not attempt to open, service, or modify this device.

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website www.monoprice.com or via email at support@monoprice.com. Check the website for support times and links.

PACKAGE CONTENTS

Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.

- 1x BT-250ANC Bluetooth® Headphones
- 1x Micro USB Charging Cable
- 1x User's Manual

CHARGING

Charge the battery before first use and at least once every three months to keep it fresh and capable of holding the full charge. Perform the following steps to charge the battery.

1. Plug the included **Micro USB Charging Cable** into the **Micro USB Port** on the headphones, then plug the other end into a USB power source, such as a wall charger or power bank (available separately). The **LED** will illuminate red to indicate that charging is in progress.
2. When the battery is fully charged, the **LED** will turn off. It takes about 2-3 hours for a full charge, depending on the output current of the USB power source.
3. Unplug the **Micro USB Charging Cable** and store it in a safe place for future use.

BLUETOOTH PAIRING

Perform the following steps to pair these headphones with your mobile device.

1. Press and hold the **▶||** button for 3 seconds to turn the headphones on. The headphones will emit a sound, the **LED** will illuminate blue, and a Bluetooth® status tone can be heard.

If the headphones were previously paired with another device and that device is powered on and within range, the headphones will reconnect to that device.

Otherwise, the headphones will enter Bluetooth pairing mode and the **LED** will flash red and blue alternately.

2. Open the Bluetooth settings on your device and scan for nearby Bluetooth devices.
3. Locate and select the **MP43550** entry. If prompted for a passcode, enter **0000** (four zeros).
4. After the headphones are paired and connected with your device, a beep can be heard and the **LED** will change to solid blue.

CONTROLS

- Press and hold the **▶||** button for 3 seconds to turn the headphones on or off.
- Momentarily press the **▶||** button to pause or resume playback.
- When an incoming call is received, momentarily press the **▶||** button to answer the call.
- With a call in progress, momentarily press the **▶||** button to hang up.
- Double press the **▶||** button to redial the last number dialed.
- Press and Hold the **+** button to skip forward to the next track.
- Momentarily press the **+** button to increase the volume level.
- Press and hold the **=** button to skip back to the previous track.
- Momentarily press the **=** button to decrease the volume level.
- Slide the ANC switch to the **ON** position to turn ANC on.
- Slide the ANC switch to the **OFF** position to turn ANC off.

SPECIFICATIONS

P/N	43550
Driver Size	40mm
Bluetooth® Version	5 + EDR
Bluetooth Range	up to 32 feet (10 meters)
Supported Bluetooth Profiles	AVCTP v1.4, AVRCP v1.5, GAVDP v1.0, AVDTP v1.0, A2DP v1.0, HF v1.5
ANC Noise Cancellation	about 18 ~ 22 dB
Battery Capacity	400mAh
Playback Time (ANC OFF)	about 12 ~ 15 hours
Standby Time	about 400 hours
Battery Charging Time	about 2 ~ 3 hours

TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website www.monoprice.com or through email by sending a message to tech@monoprice.com. Check the website for support times and links.

To download the latest drivers, firmware, manuals, etc., go to www.monoprice.com and type the P/N into the search bar. If available, support files are linked at the bottom of the product page.

REGULATORY COMPLIANCE

Notice for FCC



FCC ID: 2ADDH-43550

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifying the equipment without Monoprice's authorization may result in the equipment no longer complying with FCC requirements for Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radio Notice for FCC

Caution

This FCC Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

EU Conformity with applicable directives



This equipment complies with the essential requirements listed below:

- Radio Equipment Directive (RED) 2014/53/EU
- RoHS 2 Directive 2011/65/EU with Directive (EU) 2015/863

UK Conformity with the relevant Union harmonization legislation



This equipment complies with the essential requirements listed below:

- Radio Equipment Regulations 2017
- Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc.

The Bluetooth® word mark and logos are registered trademarks of Bluetooth SIG, Inc.

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **SHENZHEN HAOYISHI TECHNOLOGY CO., LIMITED** may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The device complies with RF exposure requirements and can be installed and used without restriction.