

尺寸: 105\*150mm



**Multi-function Bluetooth Speaker with Clock**  
Model No.: J36

Thank you for purchasing our product.  
In order to make full use of the new Multi-function Bluetooth speaker with clock, we sincerely invite you to read these instructions prior to use.

**Note:**  
Before using this product, please get this unit fully charged by using the original data charging cable.

**Contents**

Product Parameters, Features, Accessories	-----3
Button Function	-----4
Bluetooth Mode	-----6
TF Card	-----7
Time Setting	-----8
Alarm Clock Mode	-----10
Alarm Volume, 12/24-Hour Time Mode, Temperature mode	-----11
Snooze Mode, Charging Interface	-----12
Stand Unfolding	-----14

**Product Parameters**

Product Model: J36	Product Material: ABS
Bluetooth Name: Jtemen J36	Product No: W-110
Bluetooth Version: 5.0	Product Output: DC5V/2A
Speaker Power: 30W*1	Charging Time: 3-4 hours
Product Size: 105*150*15mm	Product Input: DC5V/1A


**Product Features**

- Portable mini speaker
- Adjustable phone stand
- Build-in microphone
- Handfree calling
- Screen display, date, time, week, temperature and alarm clock
- Two sets of alarm clocks with flexible settings can help you manage your time effectively and avoid missing important events

**Product Accessories**

Multi-function Bluetooth Speaker with Clock	*1
User Manual	*1
Typc-C Charging Cable	*1

**Button Function**



① + Press to increase the volume  
② - Press to decrease the volume  
③ Power on/Mode  
a. Press and hold **④** to power on the Bluetooth speaker and enter Time Mode.  
b. After the unit is powered on, Press **④** to switch it to Bluetooth mode or SD card mode. (If there is no TF card inserted, it will remain Bluetooth mode.)  
④ SNOOZE/DIMMER  
a. When the alarm goes off, press **⑨** to activate Snooze Mode, the alarm will ring again in 5 minutes. Press and hold **⑨** for 2 seconds, the alarm will be turned off.  
b. Screen brightness could be adjusted by short press **⑨**.  
⑤ Play/Pause/Answer  
Press **⑩** to pause or play. Press **⑪** to answer with hand-free speaker phone or hang up phone calls.

**Bluetooth Pair**  
Long Press **④** to disconnect bluetooth and short press **④** to reconnect bluetooth.

**⑦ Previous**  
Press **⑤** to return to the previous track.

**⑧ Next**  
Press **⑥** to go to the next track.

**⑩ Microphone**  
Reset Button

**⑪ Volume of Alarm Clock**  
Press **③** to enter Alarm Volume Setting Mode.  
⑫ Alarm Clock 1  
a. Press **⑤** to turn on/off Alarm Clock 1.  
b. Press and hold **⑤** to enter the Alarm Clock 1 Setting Mode.  
⑬ 12/24-Hour Time  
a. Press and hold **⑪** to enter 12/24-Hour Time Setting Mode.  
b. In setting mode, press and hold **⑪** to switch it to 12H or 24H.

**⑭ Temperature Mode**  
a. Press and hold **⑫** to entering Temperature °C Setting mode.  
b. In setting mode, press and hold **⑫** to switch it to °C Mode or F Mode.

**⑮ Alarm Clock 2**  
a. Press **⑤** to turn on/off Alarm Clock 2.  
b. Press and hold **⑤** to enter Alarm Clock 2 Setting Mode.

**⑯ Bluetooth Mode**  
Press and hold **④** for 3 seconds to power on the speaker, it enters Time Mode automatically, then press **④** again to enter Bluetooth Pair mode, the LED Indicator will slowly flash blue.

**⑰ Clock**  
Press and hold **⑪** 3 seconds to enter Time Setting Mode.  
Press and hold **⑪** 8 seconds to Power Off.  
After shut off the device, short press **⑨** or **④** to power on the speaker rapidly when it is connecting to power.

**⑱ TF Card Mode**  
1. In Time Mode, press **④** to switch to TF Card Mode.  
2. If there is no TF card inserted, it will not switch to TF Card Mode.  
3. The time setting steps are as below (Digital on the screen flashes when in setting mode).  
NOTE: There is a 30s time-out for the display if the Bluetooth Connection has been shut down by long pressing **⑨** for 3 seconds. (Press **⑨** or **④** the digital clock screen will be re-displayed.)

正

反