

True Wireless Earbuds

User's Guide for Model BE1039

KINLAN

Features

- Bluetooth v5.3: range approximately 60ft.
- IPX7 Waterproof protection
- Built-in microphone
- Handsfree calling
- Rechargeable battery: up to 7 hours at 50% volume


Includes

- Wireless earbuds
- Charging case
- Ear tips (small, medium, and large)
- USB-C charging cable
- User manual

Controls and Functions

Earbud Indicator LED

Red when charging.
Lights off when fully charged.



Multi-Function Button

Note: The Function Touch Pad is sensitive and must be touched or tapped to operate properly.

General

Tap and hold for 3 seconds to power ON
Tap and hold for 5 seconds to power OFF.

Phone Calls

Tap to answer/end phone calls.
Tap and hold for 2 seconds to reject incoming calls.

Voice Assist

Tap and hold for 2 seconds to activate Voice Assistant (LEFT).

Music


Tap to play/pause music.
Tap twice to skip to next track (RIGHT).
Tap twice to play previous tracks (LEFT).
Tap 3 times to turn volume up (RIGHT).
Tap 3 times to turn volume down (LEFT).

Charging the Case

The earbuds have a total battery life of approximately 7 hours at 50% volume. To charge the case, use the **USB-C to USB** cable (included), to connect to the USB port of a powered-on computer or a UL certified USB power adaptor (not included). When the case is charging the **Power Indicator LED** will light up. The total charge time for the case is approximately 2 hours.


Case Power Indicator LED Guide

■ ■ ■ ■	1%~25%(Power)
■ ■ ■	25%~50%(Power)
■ ■ ■	50%~75%(Power)
■ ■ ■	75%~99%(Power)



Charging the Earbuds

1. Open the cover and place the earbuds on the charging contacts. Be sure to match the left and right earbuds with the correct docking station in the case.
2. **Earbud Indicator LED** will turn red when charging. When fully charged, the LEDs will turn off. Charging time for the earbuds is approximately 2 hours.



Pairing Bluetooth

Note: When earbuds are powered on, they automatically link and enter pairing mode. You can power on a single earbud to use as a single unit if you wish.

1. With the earbuds powered on, you can now connect to your Bluetooth device. The **LED indicator** on the earbuds will flash red and blue, indicating it is ready to pair to a Bluetooth device.
2. On your Bluetooth device, search for nearby devices in your Bluetooth settings and select **BE1039**. When successfully connected to your Bluetooth device, a voice prompt will announce the Bluetooth connection.
3. Audio played through the connected Bluetooth device will now be heard through both earbuds. Use the controls on the connected device to play audio and adjust volume.

PLEASE NOTE: Due to the nature of truly wireless earbuds, you may experience slight interruptions with your audio in areas with multiple 2.4Ghz bands or in high wireless traffic areas.

Reconnect Bluetooth

If you have trouble connecting the earbuds and your device or if the earbuds become unpaired, do the following:

1. Delete **BE1039** from your list of devices in your Bluetooth settings
2. Press and hold the **Multi-Function Button** for 5 seconds to turn the earbuds off. Press and hold the Multi-Function button for another 3 seconds to turn the earbuds back on.
3. Return the earbuds to the case. Remove them and allow them to automatically enter pairing mode. Connect to your Bluetooth device using the steps above.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.