



DPS300

Passport Reader Quick Guide


Overview



Contents


- Features
- SAM Installation
- LED Indicators
- Package Contents
- Getting Started
- Operation
- Caution
- Support Information

Features




SAM Installation

1. Ensure that the AC adaptor cable and USB cable are unplugged from the device.
2. Unscrew and remove the SAM door.
3. Slide SAM lock downward and open the SAM holder.
4. Slot in the SAM card into the card holder with the contact area facing down and correct orientation.
5. Push the SAM holder back up and slide SAM lock upward to lock.
6. Secure the SAM door.




LED Indicators



Package Contents

Make sure your package contains the following items.



If any item is missing or appears to be damaged, please contact your vendor.

Getting Started


① System Requirements

- Intel Pentium 1 GHz CPU or higher (or other fast x86 compatible CPU).
- 512 Mbytes of RAM or more.
- Microsoft Windows XP/Vista/7 operating system.
- Integrated USB 2.0 port (on motherboard).
- VGA at min. 1024 X 768, 16 Bit colour depth.

② Driver Installation

Please refer the driver installation guide in product CD.



③ Communicate with Host



1. Connect the device to the host with USB cable.
2. Connect the device's power cable.
3. Turn on the power switch to power up.
4. Device is ready to be used once green LED indicating 'STANDBY' is lighted up.


Operation

① Travel Document Placement



Place travel document on the scanner glass.

② Contactless Card Placement



Place contactless card on the reader as shown in the diagram.

Caution



DO NOT LIFT THE UNIT BY THE HOOD

Support Information

Terms & Conditions

- Please refer to your vendor on warranty terms.
- The contents of this Quick Guide are subject to change without prior notice.
- No part of this Quick Guide may be reproduced in any form without the express written consent of the manufacturer.
- Illustrations in this document may differ from the actual unit.

Copyright Information

- Microsoft, Windows, Windows XP and the Windows logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and / or other countries.
- Microsoft products are licensed to OEMs by Microsoft Licensing, Inc., a wholly owned subsidiary of Microsoft Corporation.
- All other products and company names mentioned here in may be the trademarks of their respective owners.

PRADOTEC CORPORATION SDN. BHD.

Email: inquiry@pradotec-global.com

www.pradotec-global.com

© Copyright 2014 PRADOTEC CORPORATION SDN. BHD. All Rights Reserved.

4100-0083A0R

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.