


BOOMBOT REX WIRELESS SPEAKER



1. During cell conversation, press to mute, press again to resume, at MUTE mode with RED light
2. Press once for last track, press and hold for volume decreasing, to pick up the call
3. Press once for Play/Pause, Press and hold 2 seconds for SIRM function, When cell is coming in, press once to pick up, and press again for shut down
4. Press once for next track, press and hold for volume increasing, to pick up the call
5. Press and hold 2 seconds for power on/ off
6. MICRO USB: Need 5V 500MA for charging
7. Dame
8. LINE-IN; LINE-OUT: When insert earphone, will be mute



BOOMBOT REX QUICK START GUIDE

LED indicator:

MUTE mode with red LED light

Green : at AUX mode for green light, charging mode green light was sparking

Red : battery capacity lower than 3.5V red LED light was sparking

Blue : power on and during bluetooth pairing mode, blue LED indicator was sparking

And always for blue light when pairing successfully; charging mode is blue at bluetooth mode, and always blue when charging full

At power off mode, it is green LED sparking during charging, and then always green when full

Saving power, Power on and no bluetooth connection, will power off automatically after 10 minutes



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation