



TWINS USER MANUAL

Wireless Bluetooth Speakers

www.trendwoo.com

ACCESSORIES:

- 1x Twins Bluetooth Speaker
- 1x User Manual
- 1x USB Charging Cable
- 1x AUX 3.5mm Audio Cable

HIGHLIGHTS

Twins are compact Bluetooth speakers that can be wirelessly connected to Bluetooth devices such as smartphones, tablets and computers to playback any music collection stored on them. Thanks to the powerful battery and passive radiators, the system delivers full stereo sound and X-bass effect. Different from other mains supply, Twins support about 6 hours' continuous play time. Twins, the perfect indoor companion for you! The process control helps you get rid of complicated connections and wiring distance constraints. Therefore, users can enjoy high-quality music anytime and anywhere.

BLUETOOTH CONNECTION

At the same time, turn the two speakers on by pressing both powers for several seconds, then the two speakers connect together. Then the blue led flashes quickly. The speakers now have entered the Bluetooth pairing mode.

CONNECT TO MOBILE PHONES/TABLET PCs/ COMPUTERS

- Activate your phone's Bluetooth.
- Go to your phone's Bluetooth settings, and scan for new Bluetooth devices.
- Upon device found (Twins), click the device name and pair with it.
- If your phone ask for pairing code, please enter "0000" and confirm it.
- After successful pairing, the speakers will sound a prompt tone and the LED lights blue.

Note:

Pairing time is varied with different mobile phones. It only needs to be paired at the first time and it will auto connect the devices which have already been paired before (The speakers only can remember the last 8 paired devices' names)

BLUETOOTH CONNECTION

The speakers will show the voice instruction for incoming calls. Short press either of the single button on Twins to answer the call and talk to the speakers directly. Short press either of the single button to end the call and back to play music. Short press twice either of the single button to reject the incoming call or dial back.

AUX AUDIO-IN CONNECTOR

The speakers also feature 1x AUX audio in port, simply connect the speakers with your non-Bluetooth mobile phone/MP3 player/ PC/laptop with the 3.5mm jack audio cable. The green and blue indicator light will be on, then you can play music via wired connection.

Low power indication

The speakers will have voice hint to remind you to charge if battery is low (battery only left 10%). Users need to charge the speakers timely.

CHARGING AND COMPUTER CONNECTION


Connect the micro USB charging cable to a computer or USB charger, red Led indication for charging status.

Red LED goes off upon charging finished. (5-6 hours for charging)

SPECIFICATIONS

Speaker Interfaces

Audio input connector: 3.5mm
AUX cable: support aux external audio input.
Charging interface: Micro USB; 5V Input



Dimensions And Basic Parameters

- Length: 62 ± 0.2mm
- Width: 62 ± 0.2mm
- Height: 86 ± 0.2mm
- Weight: 257G±5G
- Material: ABS+METAL

ELECTRICAL SPECIFICATIONS

- Bluetooth Compatibility: It is compatible with Bluetooth 3.0 Class II and supports A2DP V1.2, AVRCP V1.4 profiles agreement.
- Transmission distance: up to 10 m
- Sound track: dual track
- Maximum Output: 3W×2
- Signal to noise ratio S / N: ≥ 80dB
- Frequency Range: 180Hz-20KHz
- Distortion THD: ≤ 1%
- Speaker unit: outer diameter 50mm, inner magnet, 4Q, 3W

PARAMETERS OF POWER

- Rated voltage: 3.7V DC
- Battery: built-in lithium battery, 3.7V/800mA
- Charging time: 2.5 ± 0.5 hours

Function	Operation
Answer a call	During an incoming call, short either of the single button to answer the phone, short press again hang up phone and back to play music.
End or refuse a call	Short press twice either of the single button to end the call or to refuse the call.
Power ON / OFF	Long press the two buttons at the same time to power on and long press either button to power off.
Magnet Function	The two speakers can be separated used or together. bonded by the magnets They can also stick to metals.

TROUBLE SHOOTINGS

1. My mobile phone can't find any new Bluetooth devices?
 - a) Make sure the Bluetooth speaker has entered pairing mode;
 - b) Ensure the speaker is within the effective working range;

2. Bluetooth devices can't pair up

- a) Make sure your mobile phone allows new connection, did not reach the maximum allowed connection number, please ref to your mobile's user manual
- b) Make sure the pairing password entered is "0000". If you are using a Bluetooth transmitter device, please ensure the responding password of your Bluetooth transmitter supports "0000" code.

3. My mini speaker does not play music / answer call when it connected to a Bluetooth mobile phone?
 - a) Make sure your Bluetooth mobile phone supports A2DP and HSF (hands-free) profile;
 - b) Ensure your Bluetooth cell phone is within effective working range.

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

3. My mini speaker does not play music / answer call when it connected to a Bluetooth mobile phone?

- a) Make sure your Bluetooth mobile phone supports A2DP and HSF (hands-free) profile;
- b) Ensure your Bluetooth cell phone is within effective working range.

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

4. When paired with my computer, windows ask for new driver? Can you supply?

- a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

6. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

7. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

8. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

9. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

10. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

11. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

12. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?

- a) Make sure the Bluetooth speaker has entered pairing mode;
- b) Ensure the speaker is within the effective working range;

4. When paired with my computer, windows ask for new driver? Can you supply?
 - a) We can't supply. The Bluetooth A2DP/HSF drivers may require to play stereo sound via Bluetooth connection. But the driver is actually needed for the Bluetooth module on your PC, instead of the speakers. Different Bluetooth module may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver update.

5. Why can't I remotely control the pause, play, previous song and skip track functions with the speaker when playing music?