

## FRONT




**DXP1000DVR**  
QUICK START GUIDE

This Quick Start Guide gives you the basic information to start using your DXP1000DVR. Please call customer service at 1-844-NAVATLAS, 1-544-628-2852

**NavAtlas™**  
Customer Service Toll Free: 1-844-628-2852

**Installation**




(Note : Factory bracket and screws not included)

**Control Locations**




**Fold**

**Wiring Diagram - Inputs/Outputs**



1. HDMI INPUT  
2. BT INPUT  
3. AV INPUT 3.5mm Jack  
4. VOL+ Increases volume  
5. Return: Back button for DualMirror two way control (Android phone only)  
6. Home: Home button for DualMirror two way control (Android phone only)  
7. Menu: Menu button for DualMirror two way control (Android phone only)

**Home Screen**



1. DVR Recording  
2. FM/AM Radio  
3. USB  
4. DualMirror  
5. BT Mirror  
6. Next Page  
7. BT Phone  
8. Video Player  
9. Music Player  
10. Previous Page  
11. Picture Viewer  
12. Aux Power Switches  
13. QR Code (DualMirror App)  
14. AV Input  
15. Settings Menu

**Main Menu**

In the menu mode, press the desired icon to enter the corresponding mode: Tuner, USB, DualMirror, Bluetooth Music, AV.

Tap LEFT or RIGHT arrows or Swipe to the left or right to get the next screen for more functions.

**Audio Control**

Tap Audio Setting to select between Bass, Middle, Treble, Subwoofer, EQ, Loudness, Fader/Balance, Radio Mix.

**Tuner Operation**

Select the Tuner icon from the Main Menu screen or press MODE until Tuner is selected.

1. Information Display  
2. Radio Main Menu  
3. Tune Down  
4. Previous Menu  
5. Mute On/Off  
6. Audio Control  
7. AS/PS  
8. Band 9. Next Menu  
10. Tune Up

**DVR Operation**

Press DVR 1/DVR 2 TO Make Full Screen. Press screen while in full screen mode to return to normal view.

1. DVR Recording  
2. Scroll Up  
3. To enter BT Phone  
4. Press and hold to stop recording to stop  
5. View recorded videos  
6. Enter DVR Settings  
7. Delete Video

**USB Operation**

1. Previous Page  
2. Mute  
3. Audio Control  
4. Repeat  
5. Radio Main  
6. Next Page  
7. Rew  
8. FF  
9. Loud  
10. Subwoofer  
11. AF  
12. TA  
13. UP  
14. DOWN  
15. USB File/Folder View

**DVR Operation**

Press DVR 1/DVR 2 TO Make Full Screen. Press screen while in full screen mode to return to normal view.

1. DVR Recording  
2. Scroll Up  
3. To enter BT Phone  
4. Press and hold to stop recording to stop  
5. View recorded videos  
6. Enter DVR Settings  
7. Delete Video

**AV In Operation**

1. Previous Page  
2. Mute  
3. Audio Control  
4. Loud  
5. Subwoofer  
6. Previous Page  
7. AF  
8. TA  
9. UP  
10. Down

**AV In Operation**

1. Previous Page  
2. Mute  
3. Audio Control  
4. Loud  
5. Subwoofer  
6. Previous Page  
7. AF  
8. TA  
9. UP  
10. Down

**Fold**

## BACK

**BT Phone & BT MUSIC Operation**

**Bluetooth Microphone**  
An external microphone can be mounted in an area close to the driver for better clarity.

**Pairing and Connecting**  
Before you can use a Bluetooth device, it must be paired and connected. The DXP1000DVR broadcasts the pairing signal constantly when no devices are currently connected. Complete the pairing procedure from your Bluetooth device. The device will be named "NavAtlas". The Bluetooth device code "0000". Once pairing is complete, most Bluetooth devices will connect automatically if the device is in range when the unit is powered on.

**Dialing a Number**  
Press **BT** to display keypad and dial a number.

**Making and Ending a Call**  
Press **BT** to connect a call, and press **BT** to end a call.

In order to access contacts, tap "Contact" icon. You can refresh the contact list to tap "refresh" icon.

**Accessing Recent Call List**  
Press **BT** to access the recent call list and view listed numbers from recent Received, Dialed or Missed calls.

Search the paired BT devices. Tap **BT** icon to access the list of the paired BT devices. Select the desired device name to pair.

**Streaming Audio**  
Press **BT** to enter the music control menu. Press **BT** to play or pause the music. Press **BT** to skip to the previous track. Press **BT** to advance to the next track.

**Switch Operation**  
Switch 1-4 provide a triggered 12V output for external lighting and other accessories, these triggers are meant to be used with 12V relays.

NOTE: wires provide 1A of power only

**DualMirror Operation**

The DualMirror technology allows you to mirror the screens of select android phones as well as iPhone, iPad, iPod devices onto the receivers screen for viewing navigation or other apps.

**MIRROR LINK**

1. Click on code icon on HOME screen  
2. Enter QR code  
3. When QR code shows up, scan the QR code with your Android phone  
4. Download DualMirror app from Google Play Store  
5. When the download is complete, the DualMirror app will be installed on the receiver screen  
6. Select DualMirror App installed in the Android phone  
7. Tap DMR BT SETTING to move to the BT setting screen  
8. Pair the Android phone with the DXP1000DVR unit via Bluetooth.

**BT**  
9. Connect a Android phone to the DXP1000DVR using screen Mirroring, MHL or HDMI  
10. Turn on AC/Off on Mirroring screen.

**BT**  
11. If key control does not work, check if DualMirror APK works or Bluetooth is paired or not.

See owner's manual for DMH25 wireless dongle included for more information

**QR Code Operation**

**Copyright and Trademark Notes**

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing and/or other limited authorized viewing. Macrovision's technology is intended to prevent unauthorized recording of copyrighted material. DOLBY and the double-D symbol are trademarks of Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories. DVI Logo is a trademark of Digital Video Interface, Inc. HDMI Logo is a trademark of HDMI Licensing, LLC. The SD Logo is a trademark of SD-3C, LLC. iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. Mac is a trademark of Apple Inc. All other trademarks and trade names are those of their respective owners.

3

4