


# crema *Carta*

U S E R M A N U A L  
KOREA ELECTRONICS PUBLISHING HUB

# 01 Contents

---



Crema Device



USB Cable



Manual



Warranty Card


|   |               |     |
|---|---------------|-----|
| 1 | Crema Device  | x 1 |
| 2 | USB Cable     | x 1 |
| 3 | Manual        | x 1 |
| 4 | Warranty Card | x 1 |

---

## 02 Features


---

Front




- ① Logo
- ② Panel
- ③ Home Button

Back




- |   |              |   |               |
|---|--------------|---|---------------|
| ① | Logo         | ④ | Charging Slot |
| ② | LED          | ⑤ | SD card Slot  |
| ③ | Power Button |   |               |

# 03 Registration



- Power
- Book shelf page



- Home Btn
- (Settings)
- (WiFi Settings)
- Connect to WiFi




- Book shelf page
- (Settings)
- Book store account




- Select the account



## 04 Interfaces



- ① Light, Battery, Time
- ② Refresh, Download
- ③ Edit, Search, Align, User file, Settings
- ④ Book List
- ⑤ My Shelf, Store, e-Library, Dictionary, Internet, Settings



- ① My Shelf, Contents, Refresh, Search, Switch Mode, Font, Book Mark
- ② Next Page (1page)
- ③ Next Page (Several Pages)



## FAQ

### **AfterImage and Screen Vibration**

Afterimage visible, and screen vibration after turning pages or navigating menus which has been a problem for all eink screens. It can be reduced with using optimised viewer.

### **Battery Problem**

Frequent use of WIFI and Front Light functions may consume battery life. When your device battery has completely discharged, use power button after recharge.

### **Freezing**

Because of battery or view system problems, it may stop sometimes. Plug in USB cable into the device and restart the device.

### **Panel**

Panel may break with small impact.

### **WIFI**

Because of different type of connection, WIFI may not connect at the government office or free WIFI zone.

## Notice

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

### **Information of certification**

Application's company : INNOWAVEGLOBAL Co., Ltd.

Model name : Wireless output device

Identification code : MSIP-CMI-EWG-CREMA0630L

Manufacture date : Separate Mark


Manufacturer / Manufacture Country : NETRONIX, INC / Taiwan

A/S : [www.innowaveglobal.com](http://www.innowaveglobal.com) / 031-8086-5484

---

# 07 Specification

---



| Division | Category    | Specification                     |
|----------|-------------|-----------------------------------|
| Hardware | Display     | 6" Carta Panel (Front Light)      |
|          | Size        | 163 x 114 x 8 (mm)                |
|          | Capacity    | 8GB (Maximun 32GB SDCard Support) |
|          | Touch       | Capacitive Multi Touch            |
|          | Sensor      | Auto Wake Up                      |
|          | WiFi        | WiFi 802.11n(HT20)                |
|          | Battery     | 1500mAh                           |
|          | Frequency   | 2412 ~ 2462MHz                    |
|          | Temperature | -20°C ~ 50°C                      |
| Software | Power       | DC 5V                             |
|          | System      | Android 4.0 ICS                   |
|          | Sync        | Bookmark, Underline, Memo         |
| Contents | Dictionary  | Kor/Eng                           |
|          | Format      | ePub, PDF, img zip, txt           |

---

## 품질보증

- 저희 한국이퍼브에서는 품목별 소비자 분쟁해결 기준(공정거래위원회 고시)에 따라 아래와 같이 제품에 대한 보증을 실시합니다.
- 제품의 고장이 발생하면 구입처 또는 고객센터 02-6271-7600 으로 전화 주세요.
- 보상 여부는 요청일로부터 7일 이내에 통보일로부터 14일 이내에 해결해 드립니다.
- 단순 번식에 의한 반품시에는 제품에 손상(스크래치 및 긁힘 등)이 없으며 구성품이 모두 갖춰진 상태에서만 가능하며 손상이 있거나 구성품이 누락되었을 시에는 반품이 불가합니다.

### 무상 서비스

- 구입 후 1년(보증기간) 이내에 정상적인 사용 상태에서 발생한 고장이 경우 무상 서비스를 받을 수 있습니다.  
(비고장성, 마케팅성, 과실성은 제외됨)
- 이 제품을 영업 용도로 전환하여 사용할 경우의 보증기간은 절반(6개월)으로 단축됩니다.
- 구입일자 확인이 안 될 경우 제조년월일 기준으로 3개월 경과한 날로부터 품질보증기간을 산정합니다.
- 배터리 보증기간은 6개월입니다.

| 소비자 피해 유형                 |                                           | 보상 내용        |                                         |
|---------------------------|-------------------------------------------|--------------|-----------------------------------------|
|                           |                                           | 보증기간 이내      | 보증기간 이후                                 |
| 정상적인 사용조건에서 성능·기능상의 고장 발생 | 구입 후 10개월 이내에 성능 기능상의 하자로 중요한 수리를 해야 할 경우 | 제품 교환 / 환불   | 해당 없음                                   |
|                           | 구입 후 1개월 이내에 성능 기능상의 하자로 중요한 수리를 해야 할 경우  | 제품 교환 / 무상수리 |                                         |
|                           | 제품 구입시 운송과정에서 발생한 피해                      | 제품 교환        |                                         |
|                           | 교환된 제품이 1개월 이내에 중요한 수리를 해야하는 고장이 발생한 경우   | 환급           |                                         |
|                           | 제품 교환이 불가능한 경우                            |              |                                         |
|                           | 동일한 원인으로 고장이 3회째 발생한 경우                   | 제품 교환 또는 환급  | 유상 수리                                   |
|                           | 서로 다른 원인으로 고장이 5회째 발생한 경우                 |              |                                         |
|                           | 소비자가 수리 의뢰한 제품을 사업자가 분실한 경우               |              | 정액감가상각한 금액에 10%를 가산하여 환급<br>(최고값은 구입가격) |
|                           | 부품 보증기간 이내 수리용 부품을 보유하고 있지 않아 수리가 불가능한 경우 |              |                                         |
|                           | 수리용 부품은 있으나 수리가 불가능한 경우                   |              |                                         |
| 소비자의 고의 및 과실로 인한 고장 발생    | 수리가 불가능한 경우                               |              | 유상 수리에 해당하는 금액 징수 후 제품 교환               |
|                           | 수리가 가능한 경우                                | 유상 수리        | 유상 수리                                   |

### 유상 서비스

제품의 고장이 아닌 경우 서비스를 요청하면 보증기간에 관계 없이 비용이 발생될 수 있으므로 반드시 사용설명서를 먼저 참조하세요.

#### 소비자 과실로 고장 난 경우

- 소비자가 임의로 분해, 개조하거나 사용상의 부주의(침수, 파손, 손상)로 고장이 발생한 경우
- 소비자가 데이터를 임의 조작하여 수리를 한 경우(시스템 정보, 환경설정, 루팅 등)
- 당사의 기사 또는 지정협력사 기사가 아닌 사람이 수리하여 고장이 발생한 경우
- 당사에서 미지정한 소모품, 옵션품 사용에 의해 고장이 발생한 경우  
(미인증된 자가 충전기, 급속 충전기, 배터리, 충전케이블류 등)

#### 그 밖의 경우

- 천재지변(화재, 염해, 수해, 낙뢰 등)에 의한 고장이 발생한 경우
- 소모성 부품의 수명이 다한 경우(배터리, 기억장치카드, 접속 단자 및 각종 부착물 등)

# Warranty

- KEPH (herein referred to 'we') provides one-year limited warranty according to the notice of Fair Trade Commission, under the law of Korea government.
- To make a warranty claim, please contact your original point of purchase or call Customer Service at 02-6271-7600.
- Your claim gets approved within 7 days and customer service proceeds within 14 days.
- If your device is not defective and you wish to return it within 7 days, return device must be approved as new with no scratch or damage and it must include all packing items. If the returning device is not in that condition, it may be refused to accept and we will charge extra costs for delivery and re-stocking.

## Coverage of Limited Warranty

- Within one year from retail purchase, limited warranty service is provided and covers defects under normal consumer use except damage or malfunctions caused by misuse, commercial use, negligence or other external causes.
- In case of commercial use, the device gets warranty for a half year.
- The warranty terms were in effect as of the date of your purchase. In case of no proof of retail purchase, actual term were in effect, 3 months after your device was manufactured.
- Battery part is particularly warranted for a half year.

| Claims                                             |                                                      | Services                  |                                                                          |
|----------------------------------------------------|------------------------------------------------------|---------------------------|--------------------------------------------------------------------------|
|                                                    |                                                      | Within warranty period    | Out of warranty period                                                   |
| Defects and malfunctions Under normal consumer use | Defect and malfunctions within 10 days from purchase | Replacement / Refund      | NA                                                                       |
|                                                    | Defect and malfunctions within 1 month from purchase | Replacement / Free Repair |                                                                          |
|                                                    | Damage during delivery                               | Replacement               |                                                                          |
|                                                    | Defect within 1 month from replacement of device     | Refund                    |                                                                          |
|                                                    | None replaceable                                     |                           |                                                                          |
|                                                    | 3rd claim with the same cause                        | Replacement or refund     | Repair at your expense                                                   |
|                                                    | 5th claim with each different cause                  |                           |                                                                          |
|                                                    | Missing defective device during warranty procedure   |                           | Refund with depreciated value plus additional 10% (MAX : purchase price) |
|                                                    | Non repairable without part                          |                           |                                                                          |
|                                                    | Non repairable even with part                        |                           |                                                                          |
| Defects caused by misuse or improper use           | Non repairable                                       |                           | Replacement at your expense, equivalent to repairing                     |
|                                                    | Repairable                                           | Repair at your expense    | Repair at your expense                                                   |

## Exception to Limited Warranty

If your device is not defective, it may occur any expense regardless of warranty terms. Please refer to user's manual prior to your claim.

### Cases of defects and malfunctions caused by consumer's misuse

- Caused by unauthorized tampering, modification and negligent use.
- Caused by unauthorized access to devices's SW and attempt on rooting.
- Attempted to repair by unqualified personnel.
- Being used unauthorized consumable items, accessories, such as non certified charger, or quick charger, battery and charging cable, etc.

### Else cases

- Caused by natural disaster such as fire, flood, lighting and etc.
- Caused by dead of consumable part such as batteries, memory cards, connectors, and other attached item.

### FCC Part 15. 105(b) : Digital Device or Peripheral device

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

### FCC Part 15. 19(a) : Certification

This device complies with Part 15 of the FCC's Rules. Operation is subject to the following two Conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesirable operation.

### FCC Part 15. 21 : Caution

Caution: Any changed or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

---