







尺寸 : 280x100mm

 <p>User's Guide for Battery WiFi Camera</p>	<p>Product Features</p> <ul style="list-style-type: none"> 2x18650 batteries work regularly for 2~4 months FHD Megapixels collocated with wide-angle lens Support mobile phone remote fast wake-up within 6 second 2.4G Wi-Fi connection Support PIR motion detection, when someone hovers at the door, it will send push alerts to your mobile phone immediately With IR-cut, it can switch automatically and it is clearly visible at both day and night to keep your home and family safe Support to power by USB port 	<p>Product Specification Sheet</p> <table border="1"> <tbody> <tr> <td>Lens</td> <td>FOV/130°Wide-angle lens (4Glass)</td> </tr> <tr> <td>Infrared LEDs</td> <td>10 pcs Infrared LEDs with 8 meters flash distance</td> </tr> <tr> <td>PIR Motion Sensor</td> <td>4~6 meters PIR distance</td> </tr> <tr> <td>Storage</td> <td>Up to 128GB Micro SD card</td> </tr> <tr> <td>Connectivity</td> <td>802.11b/g/n Wi-Fi@2.4G</td> </tr> <tr> <td>Power consumption</td> <td>Standby 200uA Working 260mA</td> </tr> <tr> <td>Battery</td> <td>2x18650 batteries</td> </tr> <tr> <td>USB</td> <td>DC5V</td> </tr> <tr> <td>Wi-Fi distance</td> <td>60 meters (open space without obstacle)15 meters (indoor)</td> </tr> <tr> <td>Video Compression</td> <td>H.264</td> </tr> <tr> <td>Voice Intercom</td> <td>Two-way audio with noise cancellation</td> </tr> <tr> <td>Video resolution</td> <td>1920*1080@15fps</td> </tr> <tr> <td>Working Temperature</td> <td>-10~ 55°C</td> </tr> <tr> <td>Storage Temperature</td> <td>-20~ 60°C</td> </tr> </tbody> </table>	Lens	FOV/130°Wide-angle lens (4Glass)	Infrared LEDs	10 pcs Infrared LEDs with 8 meters flash distance	PIR Motion Sensor	4~6 meters PIR distance	Storage	Up to 128GB Micro SD card	Connectivity	802.11b/g/n Wi-Fi@2.4G	Power consumption	Standby 200uA Working 260mA	Battery	2x18650 batteries	USB	DC5V	Wi-Fi distance	60 meters (open space without obstacle)15 meters (indoor)	Video Compression	H.264	Voice Intercom	Two-way audio with noise cancellation	Video resolution	1920*1080@15fps	Working Temperature	-10~ 55°C	Storage Temperature	-20~ 60°C	<p>Product Design</p>  <ul style="list-style-type: none"> ①Lens ②Mic ③Light sensor ④LED ⑤Motion detection sensor ⑥Charge LED ⑦USB interface ⑧Speaker <p>Charge LED: Charging in Red; Full in Green.</p>
Lens	FOV/130°Wide-angle lens (4Glass)																														
Infrared LEDs	10 pcs Infrared LEDs with 8 meters flash distance																														
PIR Motion Sensor	4~6 meters PIR distance																														
Storage	Up to 128GB Micro SD card																														
Connectivity	802.11b/g/n Wi-Fi@2.4G																														
Power consumption	Standby 200uA Working 260mA																														
Battery	2x18650 batteries																														
USB	DC5V																														
Wi-Fi distance	60 meters (open space without obstacle)15 meters (indoor)																														
Video Compression	H.264																														
Voice Intercom	Two-way audio with noise cancellation																														
Video resolution	1920*1080@15fps																														
Working Temperature	-10~ 55°C																														
Storage Temperature	-20~ 60°C																														

 <ul style="list-style-type: none"> ①Reset button ②Mirco-SD card ③Power button ④18650 Battery ⑤Flip Switch 	<p>Install your camera</p> <p>Step 1: Please put the flip switch to "open"position and open the cover, then Install 18650 battery and Mirco-SD. (Please notice the polarity of the battery). Press the Reset button long until you hear the "system reset" prompt from the camera speaker.</p>  <p>Note: Please notice the polarity of the battery. Please full charge this camera before using it for the first time.</p>	<p>Step 2: Install anchors (on stucco, brick or concrete) On stucco, brick or concrete, use the bit to drill one holes in your wall, and install the anchors.install the base bracket on the wall</p>  <p>Step 3: Align the device to the base bracket and hold it, then adjust the appropriate angle, the installation is finished</p> 	<p>Notes:</p> <ol style="list-style-type: none"> 1. USB interface is only used as power supply. 2. The mobile phone connects to the Wi-Fi of the home router, and the mobile APP can generate a QR code that made of router Wi-Fi name and password. The product recognizes the QR code through the lens on the product, and the product is automatically connected to the router and server after identification. At this time, the APP also finds the product through the server, and the APP can control the operation of the product through the network.
--	---	--	--

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.