


Reach Selfie Stick Instruction Manual



LED1: Red while recharging, it will turn off when finished recharging.


LED2: Solid means selfie stick is on. Blinking indicates Bluetooth pairing mode.

LED3: Light is blue when taking pictures.

INSTRUCTIONS

Step 1: Switch on your Bluetooth on your phone or camera.


Step 2: Long press the button for 3 seconds after the start of the Bluetooth pairing mode.



Long-press the key for 3s, the blue light will flash and the camera enters the Bluetooth pairing mode.

Step 3: When your phone is in the pairing mode, choose the Bluetooth connection named "Reach" and pair the device with the selfie stick.

Step 4: Rotate the mobile clip 270 degrees and then hold the two sides of the selfie stick to stretch slowly step by step.




Step 5: Put the mobile to the clip and open the camera function on your mobile to take a picture by pressing the camera button on the selfie stick.

NOTE: This Selfie Stick will not work with Windows phones. Some HTC phones require you to change the phone's settings so that the volume buttons take the photos.

Enjoy!

Reach Selfie Stick Instruction Manual



FCC warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio Frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.