


User Manual

Wireless Sealed Silicone Mouse



① Mouse scroll bar	⑥ Label
② Left button	⑦ Wireless charging location identification
③ Right button	⑧ Charger port (Via 5V, 1A or 2A power adapter)
④ Indicator	⑨ 2.4GHz Adapter
⑤ non-slip mat	⑩ User Manual

Specification:

Number of keys: Scroll bar+ left and right button
Protection level (max): IP68
Dimension: 120*70*38mm

Operating temperature: 0°C to +45 °C
Storage temperature: -10°C to +50°C
Certification: CE, IP68, RoHS, EN60601-1

SLEEP MODE

- To maximize battery life, mouse will enter sleep mode after 10 minutes of not being in use.
- The mouse will awake from sleep mode by pressing any key.

2.4GHz MODE

Easy to use, the mouse is connected to 2.4GHz adapter with factory default setting. You just need to plug in adapter to computer, to play for your first time to use it.

BLUETOOTH MODE

1. Long press the mouse right key+middle key at the same time until the yellow indicator flashes(Hold 60 seconds) ,then release.
2. Click the Settings icon on your device.
3. Search and select “Bluetooth” on your device’s “General” menu.
4. On the subdirectory of “Devices” , select device name “Wireless Mouse”
5. The Bluetooth mouse should now show connection on your device’s menu, indicator will be yellow.
6. If your device goes into standby mode, the Bluetooth mouse should still be synced.
If you power-off your device, you may need to re-sync it.
If you use the Bluetooth mouse with a new device, or it doesn’t connect properly, follow the steps above to re-sync.

How to switch between Bluetooth and 2.4GHz Mode

2.4GHz Mode(press the left key+middle key at the same time until the green indicator illuminated(Hold 10 seconds) then release)

Bluetooth Mode(press the right key+middle key at the same time until the yellow indicator illuminated(Hold 10 seconds) then release)

BLUETOOTH COMPATIBILITY

Windows Compatibility	Windows 10 or later
Mac Compatibility	Mac OS X 10.10 or later
Smartphone and Tablet Compatibility	Android tablet or Smartphone with Android 4.0 or later. Bluetooth Smart ready device with mouse support required (Bluetooth HID)

CHARGING THE MOUSE

- Plug the wireless charger (Via 5V, 1A or 2A power adapter)
- Place the mouse and wireless charger as shown in the right figureThe mouse indicator will illuminate in red during charging. The indicator turns in green when the battery is fully charged.
- The mouse takes approximately 3 hours to be fully charged.
- The mouse indicator will blink when the mouse’s battery needs recharging.



FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.