




### ➤ English Manual

- "  "Short press this button:next song;  
long press:Volume up.Don't work  
In AUX mode.
- "  "Short press this button:previous  
song; long press:Volume down.  
Don't work in AUX mode.
- "  "Pause/Play

### ➤ Bluetooth Pairing


- Make sure the Bluetooth Speaker is in  
The off state.
- Press ON/OFF key to Bluetooth mode,  
blue LED will flash 6 times.And short  
press Play/Pause key,blue and red LED  
flash alternately.
- Follow the operating instruction of your  
mobile phone for Bluetooth and allow  
your mobile to searching Bluetooth  
headset state.Typically,this is done by  
going to "set up", "connect"or"Bluetooth"  
menu and then selecting the option to  
search Bluetooth devices.
- The mobile can see GH-BT3500 Bluetooth  
Speaker and ask if you wish to connect  
Your mobile with this speaker.Press"Yes"  
Or "Confirm"to confirm this action.

- Enter password or PIN 0000,and press  
"yes"or"Confirm".(Important notice:  
If the connection is successful,blue LED  
Will flash.If the pairing is unsuccessful,  
The LED Blue and Red will still flash  
alternately.You need to pair again.


### ➤ Flashing Instruction

Bluetooth pairing  
Red LED ON:Charge  
Red LED OFF:Full power  
Du Du Du three sound:Low power




Multifunction Button



### ➤ Jack Instruction



### ➤ Specifications

-  AUX Input plug  
While work with AUX,it is easily to listen  
to sound from PC,ipod/iphone,MP3/MP4.
-  Bluetooth Handfree  
work with the Bluetooth for wireless  
communication.
-  Stereo Bluetooth  
stereo Bluetooth Speakers,supporting  
A2DP/AVRCP,allow you enjoy wireless  
hi-Fi stereo music.

### ➤ Features

Battery voltage:3.7V	Capacity:300mAh
----------------------	-----------------

Charge voltage:5V	Louds speakers size:45mm4Ω 3W
Net weight: 230g	S/N: ≥95Db
Distortion:≤0.5%	Size:80*60*50mm

### ➤ Notice

- Do not let children play the product
- Do not hit or beat the product..
- Do not use in very humid and high  
temperature environments.Product  
performance will decrease when it is  
used in cold regions.
- Do not throw the product into fire.
- Do not block speaker's net above the body.
- Please send to repair when the product is  
Broken.Do not disassemble it by yourself.
- It's not covered under warranty when the  
product has metal of rust,surface spalling  
and other natural oxidation.

### ➤ Warranty Card

When Purchasing this product,pls fill in  
this card and be properly preserved.

Product Name: \_\_\_\_\_  
Purchase Date: \_\_\_\_\_  
Customer Name: \_\_\_\_\_  
Customer Tel: \_\_\_\_\_  
Customer Add: \_\_\_\_\_

Distribution: \_\_\_\_\_  
Distributor Tel: \_\_\_\_\_  
Distributor Add: \_\_\_\_\_

Signature: \_\_\_\_\_

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.