



USER'S MANUAL - Rubik's Bluetooth Speaker


Bluetooth Speaker Instructions:

To ensure life of the product and personal safety, please review all instructions prior to use.

1 Charging the Speaker


Plug the supplied USB connector into your Bluetooth Speaker's Charge Port. The LED indicator will turn red when speaker is charging. And will turn off when charging is complete.

Charging Recommendation:
First charging time: 12H
Following times: 2H
Runtime (continuous): 3h-3h30.



2 Bluetooth Pairing

Press and hold the Power Button for 3 seconds. The LED indicator will flash blue when ready to pair. Follow the prompted instructions on your device to complete pairing (the speaker is identified as "RUBIK'S" in your Bluetooth menu). To pause and play music, tap the Power Button. To control volume, use the volume controls on your paired device.



3 Caution and Safety

- Do not immerse in water or expose to moisture, excessive sunlight or heat
- Store in a cool, dry place
- Do not expose to flame
- Avoid excessive impact
- Discontinue use if the speaker is damaged
- Do not attempt to disassemble, modify or repair

TM & © SMTUK



FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.