




kitvision™

JB. 4366 / Made in China / © Kitvision Ltd 2015.  
Christchurch, Dorset, BH23 4FL, UK



Please recycle this packaging responsibly.

All trademarks are acknowledged as the property of their respective owners. Unless otherwise stated their use does not imply that the trademark owner is affiliated with Kitvision or endorses the products herein.

# Pocket Selfie Stick

User Manual



**Please read this manual carefully before use**

### **Box Contents**


- Bluetooth Pocket Selfie Stick
- Micro USB cable
- Phone holder
- User manual



2

### **Functions**

1. Smartphone holder
2. Side-screw
3. Telescopic section
4. Shutter button
5. Rubber grip
6. LED indicator
7. Micro USB port
8. Power switch



3





## Charging

1. Using the micro USB charging cable, connect the micro USB connector to the micro USB port (7) on the base of the Selfie Stick, and the other to a PC USB port
2. The LED indicator (6) will illuminate solid red on the base whilst charging
3. When fully charged the LED indicator (6) will turn off

## Operation

1. Turn the Selfie Stick on by sliding the power switch (8) to the ON position
2. Make sure your smartphone is turned on and Bluetooth is activated

3. Open the Bluetooth settings on your smartphone and connect to 'KV Pocket Selfie Stick'
4. Open your smartphone's camera application
5. Place your smartphone in the phone holder, by pulling the top grip upwards. Ensure it is well secured
6. Adjust the tilt of the smartphone holder (1) to gain the desired angle and tighten using the side-screw (2)
7. Extend the Selfie Stick by pulling the telescopic section outwards (3)
8. Press the camera shutter button (4) to take a photo
9. Slide the power switch (8) to the OFF position to turn the Bluetooth Selfie Stick off when finished





## Re-pairing or Pairing New Devices

1. Make sure the Bluetooth is turned off on any previously paired devices
2. Make sure the Bluetooth Selfie Stick is in Bluetooth mode and the LED indicator (6) is flashing red
3. If the LED indicator (6) is not flashing red, reset the Bluetooth Selfie Stick by sliding the power switch (8) OFF and ON
4. Follow step 2 onwards in the 'Operation' section of this user manual to pair your new device



## LED Status

- Red LED on: Charging
- Red LED off: Fully charged
- Red LED flashing: Looking for devices

## Care for your Bluetooth Selfie Stick

### Please Don't:

- Dismantle the Bluetooth Selfie Stick
- Use corrosive solvent to clean
- Operate or charge under high temperatures or strong light
- Operate in the rain or if Bluetooth Selfie Stick is wet
- Use near fire





## Specification

Support:	Bluetooth compatible Android (3.0 and above) iOS (4.0 and above) devices
Bluetooth Version:	3.0
Length (collapsed):	13.5 cm
Length (extended):	63 cm
Weight:	70 g
Battery:	3.7 V, 60 mAh

Charging time:	30 mins
Standby time:	70 hours
Smartphone width:	55 mm – 70 mm
Max weight:	400 g
Telescopic sections:	6



## Troubleshooting

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us on: [support@kitvision.co.uk](mailto:support@kitvision.co.uk)

## Notes

- Bluetooth remote is compatible with most iOS and Android smartphones
- The Bluetooth Selfie Stick will go into sleep mode after being inactive for 2 hours, press the camera remote button to wake up
- The Bluetooth Selfie Stick may conflict with some smartphone keyboards, if you have this issue simply disconnect or turn the Bluetooth Selfie Stick off



Please do not attempt to open this product. There are no user serviceable parts inside, in particular if your product has an embedded, non-replaceable battery, do not attempt to access or remove the battery as this may cause personal injury and will damage the product.

Making any attempt to open the product or carry out repair voids any and all warranties.

Kitvision will accept no liability for any damage caused to a mobile device whilst using the selfie stick.

We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.



### **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications made to this device not expressly approved by Canglu Outdoor Products Co., LTD may void the FCC authorization to operate this device.

**Note:** The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.