

# Double Sided

**Smart 5GHz WiFi  
1000 Lumens Light Bulb  
P/T Security Camera**

Scan the QR code to upgrade your warranty

From 1 Year to 2 Year Limited Warranty Item#EOP1-1003

**QUICK START GUIDE**  
EOP1-1003

v1.2 0225

## GETTING STARTED

Thank you for choosing the **Energizer** Smart Light Bulb Security Camera. This quick start guide will help you with setup and installation.

**Package Includes:**

- Smart 5GHz WiFi Light Bulb Security P/T Camera
- Socket Extender
- Quick Start Guide

**ESTIMATED SETUP** 5-10 minutes

## CONNECT THE DEVICE

**STEP 1**  
Download the free **Energizer** Connect app from the App Store (for iPhones) or Google Play Store (for Android phones).

**What You Need:**

- App
- 2.4GHz or 5GHz WiFi

**STEP 2**  
Make sure your mobile device is connected to your **2.4GHz** or **5GHz WiFi** network.

Open the app and **click "Create Account"** by following the on-screen instructions.

**STEP 3**  
Turn off the power of the light socket. Screw the Smart Light Bulb Security Camera into the light socket. Then turn power back on.

Please note, each time power is provided to the camera, it will pan and tilt to calibrate itself.

The indicator light on the camera should start blinking for pairing mode. The camera will also make a chime sound, letting you know it has started up.

Red	Blinking	Pairing Mode
Solid	Solid	Starting Up
Blue	Blinking	Attempting to Pair
Solid	Solid	Connected

If the LED is not blinking, then you are not in pairing mode. You need to manually rotate the camera and use your finger to **hold down** the reset button for 5 seconds until you hear the camera make a chime sound.

**STEP 4**  
After logging in, **click "+"** on the top right of the screen and **select "Add device"**.

The app will detect the WiFi+BLE enabled device and ask if you want to **add it**.

Make sure the check is marked next to the device you want to add, **click the "+" button**.

**STEP 5**  
**Select** the Camera category and **confirm** the indicator light is still blinking red. **Click "Next Step"**.

**STEP 6**  
**Select** the Camera category and **confirm** the indicator light is still blinking red. **Click "Next Step"**.

**STEP 7**  
**Enter and Click** the **Enter Wi-Fi Password** field and **Confirm**.

**STEP 8**  
**Confirm** that the displayed WiFi network is your **2.4GHz** or **5GHz WiFi** network, **enter** your WiFi password and **click "Confirm"**.

**TIP:** You can put your camera directly in a room by selecting one of the available rooms. **Click** the **button** to change the name of the product.

**INSTALLATION**  
Turn off the power of the light socket. Screw the socket P/T camera into the light socket. Then turn power back on.

**NOTE:** Fits Standard E26/E27 Bulb Sockets

## MULTI-WHITE LED LIGHT

Operate the built-in, multi-white LED light and set schedules to turn it on/off automatically.

**How to control the LED light:**

**TOP SLIDING SCALE:** Change the hue from maximum hue warm white (0%) to maximum hue cool white (100%).

**BOTTOM SLIDING SCALE:** Dim the light intensity from 0-100%.

**SWITCH:** Turn on/off the LED light.

**TIMING:** Create a schedule that will turn the LED light on/off automatically on pre-set times and days of the week (note that the light hue cannot be customized in this feature).

**NOTE:** You can also turn the LED light on/off with one click by pressing the power button beside your device on the main app screen.

10

## PRODUCT DETAILS

Scan the QR code below to go to our website to see product details, updated manuals, advanced features and instructional videos

11

## VOICE ACTIVATION

**Voice Activation for the Google Assistant**  
Make sure your Google Assistant device is installed and set up first.

**NOTE:** Google Assistant voice activation feature is only for controlling the light, it will not work for the camera operations.

**Voice Activation for Alexa**  
Make sure your Alexa device is installed and set up first.

**STEP 1**  
Open your Alexa app.

**STEP 2**  
Open the menu to search for "Skills".

**STEP 3**  
Search for & **choose** **Energizer** Connect.

**STEP 4**  
**Click** "Have something already set up?"

**STEP 5**  
Search for & **choose** **Energizer** Connect.

**STEP 6**  
Authorize your account with the Alexa skill using the username and password from your **Energizer** Connect app.

**STEP 7**  
Using the name you assigned your camera, you can ask Alexa to turn on/off your light.  
Ex: "Alexa, turn on the **patio** light".

12

**Voice Activation for the Google Assistant**  
Make sure your Google Assistant device is installed and set up first.

**NOTE:** Alexa voice activation feature is only for controlling the light, it will not work for the camera operations.

**Voice Activation for Alexa**  
Make sure your Alexa device is installed and set up first.

**STEP 1**  
Open your Google Home app.

**STEP 2**  
**Click** the "+" to add a new device.

**STEP 3**  
**Click** "Set up device".

**STEP 4**  
**Click** "Have something already set up?"

**STEP 5**  
Search for & **choose** **Energizer** Connect.

**STEP 6**  
Authorize your account with the Google Assistant skill using the username and password from your **Energizer** Connect app.

**STEP 7**  
Using the name you assigned your camera, you can ask the Google Assistant to turn on/off your light.  
Ex: "Ok Google, turn on the **patio** light".

13

## LEGAL & WARRANTY

**Voice Activation for the Google Assistant**  
Make sure your Google Assistant device is installed and set up first.

**NOTE:** Google Assistant voice activation feature is only for controlling the light, it will not work for the camera operations.

**Voice Activation for Alexa**  
Make sure your Alexa device is installed and set up first.

**STEP 1**  
Open your Alexa app.

**STEP 2**  
Open the menu to search for "Skills".

**STEP 3**  
Search for & **choose** **Energizer** Connect.

**STEP 4**  
**Click** "Have something already set up?"

**STEP 5**  
Search for & **choose** **Energizer** Connect.

**STEP 6**  
Authorize your account with the Alexa skill using the username and password from your **Energizer** Connect app.

**STEP 7**  
Using the name you assigned your camera, you can ask Alexa to turn on/off your light.  
Ex: "Alexa, turn on the **patio** light".

14

## LEGAL & WARRANTY

**Voice Activation for the Google Assistant**  
Make sure your Google Assistant device is installed and set up first.

**NOTE:** Google Assistant voice activation feature is only for controlling the light, it will not work for the camera operations.

**Voice Activation for Alexa**  
Make sure your Alexa device is installed and set up first.

**STEP 1**  
Open your Google Home app.

**STEP 2**  
**Click** the "+" to add a new device.

**STEP 3**  
**Click** "Set up device".

**STEP 4**  
**Click** "Have something already set up?"

**STEP 5**  
Search for & **choose** **Energizer** Connect.

**STEP 6**  
Authorize your account with the Google Assistant skill using the username and password from your **Energizer** Connect app.

**STEP 7**  
Using the name you assigned your camera, you can ask the Google Assistant to turn on/off your light.  
Ex: "Ok Google, turn on the **patio** light".

15

## TROUBLESHOOTING

**Having Trouble with Setup?**  
Don't return this product to the retailer, we're here to help. Please call us at 888-693-4189 or visit [www.energizerconnect.com](http://www.energizerconnect.com) for video tutorials, updated manuals and more FAQs for your device.

**My device won't connect to my network!**  
1. Make sure you are connected to your **2.4 GHz network** and your device is blinking red before you start trying to connect your device.  
2. You may need to reset your device if you are having trouble. Check out page 2 for the location of your device's reset button.  
3. To allow the app to locate the network, you may need to allow permissions for location and turn on your Bluetooth.  
4. If you are not certain what type of network you have, contact your Internet Service Provider and ask them to create a separate, dedicated **2.4GHz network**. You can also do this manually in your router's settings.  
5. Try moving to a spot closer to your router for connecting.  
6. You can also purchase a WiFi extender to increase your WiFi range and strength.  
7. In some cases, you can try using the secondary pairing mode by clicking "Net Pairing Mode" on the Add Device screen (see bottom of page 3). Follow the on-screen instructions.  
4. If you are using a microSD card, it will continue to record until the microSD card fills up.  
--If you are using Motion based recording: Separate files are recorded for each detection, so when the memory fills up, it will begin to record over the oldest detections, one at a time.  
--If you are using All Day recording: One files is saved as the video is continuously recording. When the memory fills up, it will clear the entire recording and start fresh.

**When my camera is pointed at a window at night, I can't see through the glare!**  
1. By default, the camera will only use the microphone if the speaker. When you click the microphone on the live view, you will be able to speak through the camera, and when you click the microphone again to turn it off, the speaker will automatically turn on so you can hear what's being said at the camera.

**When I try to view live view, it says "Offline" or "Cannot establish encryption channel!"**  
1. Unplug your camera from power and plug it back in.  
2. Check to make sure you have the newest firmware for your camera. Go to the device settings and scroll down to Firmware information.  
3. Contact us so we can assist you.

**Setting up Motion Detection and Recording**  
1. From the live view of the camera, click Notifications, or from the device settings click Detection Settings.  
--You can schedule when you want to receive notification of motion.  
2. To save recordings, you can purchase Cloud Recording or install a microSD card (16GB, not included) into the camera for LOCAL recordings.  
--Recordings can be based of motion or can be All Day.  
--Please note: All Day recording will fill up a microSD card much quicker.  
3. Every time a motion is detected, a screenshot is saved for your review. They can be found in the Notification Center. From the Home page, click the **three lines** in the top left, and then click Notifications.  
4. If you are using a microSD card, it will continue to record until the microSD card fills up.  
--If you are using Motion based recording: Separate files are recorded for each detection, so when the memory fills up, it will begin to record over the oldest detections, one at a time.  
--If you are using All Day recording: One files is saved as the video is continuously recording. When the memory fills up, it will clear the entire recording and start fresh.

16

**Two Way Audio**  
1. By default, the camera will only use the microphone if the speaker. When you click the microphone on the live view, you will be able to speak through the camera, and when you click the microphone again to turn it off, the speaker will automatically turn on so you can hear what's being said at the camera.

**Why Does It Need The Internet?**  
1. Our devices must connect to an Internet server in order to be fully operational, otherwise they will not work as desired.

**Why Does The App Need Location Permission To Function?**  
1. The latest mobile phone operating systems require location permission to access your Wi-Fi and to detect your WiFi name.

**Why Does The App Ask For Permission To Use My Microphone?**  
1. Since the app can be used with camera(s) and it's 2-way talk feature, Google's current Terms of Service requests microphone permissions when initially creating the account for device setup.

**What's A Mixed Network?**  
1. Most newer routers are dual band and broadcast a separate 2.4GHz and 5.0GHz network band. By default, they are setup to use the same Wi-Fi name and password for both. This combined dual network with the same name and password is referred to as a "Mixed Network."

**My "Live View" Isn't Working When I Access The App!**  
1. If "Live View" is not working, leave the **Energizer Connect** app and go to your phone's settings. Go to the Apps settings, locate the **Energizer Connect** app, storage, and then clear cache.

17