

Double Sided

Energizer
SMART 5GHz WiFi
INDOOR/OUTDOOR
SOCKET P/T CAMERA

Scan the QR code to upgrade your warranty

From 1 Year to 2 Year
Limited Warranty
Item#EOP1-1004

**QUICK
START GUIDE**
EOP1-1004 V1.1 0125

GETTING STARTED

Thank you for choosing the **Energizer** Smart Socket P/T Camera. This quick start guide will help you with setup and installation.

ESTIMATED SETUP 5-10 minutes

Package Includes:

- 3 Smart 5GHz WiFi Indoor/Outdoor Socket P/T Camera
- 3 Socket Extender
- Reset Tool
- Quick Start Guide

What You Need:

- App
- 2.4GHz or 5GHz WiFi

STEP 1
Download the free **Energizer** Connect app from the App Store (for iPhones) or Google Play Store (for Android phones).

STEP 2
Make sure your mobile device is connected to your **2.4GHz or 5GHz WiFi** network.
Open the app and click "Create Account" by following the on-screen instructions.
After your initial sign in, your app will remember your password and log you in automatically. You can also choose to manually log out under Settings in the Main menu.
Tip: If you would like to install a micro SD card, insert it as shown with the gold pins facing the lens. (micro SD card not included)

STEP 3
Turn off the power of the light socket. Screw the Smart Socket P/T Camera into the light socket. Then turn power back on.
Please note, each time power is provided to the camera, it will pan and tilt to calibrate itself.
The indicator light on the camera should start blinking for pairing mode. The camera will also make a chime sound, letting you know it has started up.

STEP 4
After logging in, click "+" on the top right of the screen and select "Add device".
The app will detect the WiFi+BLE enabled device and ask if you want to add it.
Make sure the check is marked next to the device you want to add, click the "+" button.
NOTE: Once successful then go directly to Step 7. If the app does not detect your device, skip this part and proceed to Step 5.

STEP 5
Select the Camera category and confirm the indicator light is still blinking red.
Click "Next Step".
Help: If you need information about **2.4GHz WiFi or 5GHz networks**, click the link for more information

STEP 6
Confirm that the displayed WiFi network is your **2.4GHz or 5GHz WiFi** network, enter your WiFi password and click "Confirm".
Help: If you need information about **2.4GHz WiFi or 5GHz networks**, click the link for more information

STEP 7
On the next screen, a QR code will appear. Position your camera to scan the QR code that shows on your phone.
Click "Continue" when you are ready.
Touch the lens of the camera directly against the QR code on your phone and slowly move the camera away.
Once you hear an audible prompt from the camera, click the "I Heard a Prompt" button.
Help: If you don't hear the prompt, try pairing using EZ mode. Take a look at troubleshooting on page 14.

STEP 8
Your Smart Camera will now be connected to the network. Confirm the settings for your device and then Click "Done".
TIP: You can put your camera directly in a room by selecting one of the available rooms. Click the button to change the name of the product.
PROCESSING TIME 1-2 minutes

PRODUCT DETAILS

Scan the QR code below to go to our website to see product details, updated manuals, advanced features and instructional videos

VOICE ACTIVATION

To enable voice access for your Smart Camera, you will need to link the **Energizer** Connect skill with your choice of voice assistant.

Voice Activation for Alexa

Make sure your Alexa device is installed and set up first.

STEP 1 Open your Alexa app.
STEP 2 Open the menu to search for "Skills".
STEP 3 Search for & choose **Energizer** Connect.
STEP 4 Authorize your account with the Alexa skill using the username and password from your **Energizer** Connect app.
STEP 5 Using the name you assigned your camera, you can ask Alexa to turn on/off your camera.
Ex: "Alexa, show me the *patio* camera".

Voice Activation for the Google Assistant

Make sure your Google Assistant device is installed and set up first.

STEP 1 Open your Google Home app.
STEP 2 Click the "+" to add a new device.
STEP 3 Click "Set up device".
STEP 4 Click "Have something already set up?" Search for & choose **Energizer** Connect.
STEP 5 Click "Choose".
STEP 6 Authorize your account with the Google Assistant skill using the username and password from your **Energizer** Connect app.
STEP 7 Using the name you assigned your camera, you can ask the Google Assistant to turn on/off your camera.
Ex: "Ok Google, show me the *patio* camera".

LEGAL & WARRANTY

Warranty
To see Warranty information and Certification Legal warnings, please see our website.
www.energizerconnect.com

FCC Compliance
This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS

Cautionary Marking:
DO NOT USE WITH STANDARD DIMMERS. SEE INSTRUCTIONS
NE PAS UTILISER AVEC DES GRADUATEURS STANDARD. VOIR LES INSTRUCTIONS
RISK OF ELECTRICAL SHOCK - USE IN DRY LOCATION ONLY
RISQUE DE CHOC ELECTRIQUE - UTILISER DANS UN EMBLACEMENT SEC UNIQUEMENT
NOT FOR USE IN TOTALLY ENCLOSED LUMINAIRES
NE CONVIENT PAS A DES LUMINAIRES TOTALEMENT FERMES

LEGAL & WARRANTY

Warranty
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

FCC Compliance
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS

Cautionary Marking:
DO NOT USE WITH STANDARD DIMMERS. SEE INSTRUCTIONS
NE PAS UTILISER AVEC DES GRADUATEURS STANDARD. VOIR LES INSTRUCTIONS
RISK OF ELECTRICAL SHOCK - USE IN DRY LOCATION ONLY
RISQUE DE CHOC ELECTRIQUE - UTILISER DANS UN EMBLACEMENT SEC UNIQUEMENT
NOT FOR USE IN TOTALLY ENCLOSED LUMINAIRES
NE CONVIENT PAS A DES LUMINAIRES TOTALEMENT FERMES

TROUBLESHOOTING

HAVING TROUBLE WITH SETUP?

When I try to view live view, it says "Offline" or "Cannot establish encryption channel!"
1. Unplug your camera from power and plug it back in.
2. Check to make sure you have the newest firmware for your camera. Go to the device settings and scroll down to Firmware Information.
3. Contact us so we can assist you.

My device won't connect to my network!
1. Make sure you are connected to your **2.4GHz or 5GHz network** and your device is blinking red before you start trying to connect your device.
2. You may need to reset your device if you are having trouble. Check out page 2 for the location of your device's reset button.
3. To allow the app to locate the network, you may need to allow permissions for location and turn on your Bluetooth.
4. Try moving to a spot closer to your router for connecting.
5. You can also purchase a WiFi extender to increase your WiFi range and strength.
6. In some cases, you can try using the secondary pairing mode by clicking "Net Pairing Mode" on the Add Device screen (see bottom of page 3). Follow the on-screen instructions.

When my camera is pointed at a window at night, I can't see through the glare!
1. At night, the camera's IR LEDs will turn on automatically to provide night vision when it gets dark. IR light reflects off of glass. So if you are trying to use your Indoor Camera through a window at night, go into the Device Settings->IR Night Vision and set it to OFF.

Why Does It Need The Internet?
1. Our devices must connect to an internet server in order to be fully operational, otherwise they will not work as desired.

Why Does The App Need Location Permission To Function?
1. The latest mobile phone operating systems require location permission to access your Wi-Fi and to detect your Wi-Fi name.

Why Does The App Ask For Permission To Use My Microphone?
1. Since the app can be used with camera(s) and it's 2-way talk feature, Google's current Terms of Service requests microphone permissions when initially creating the account for device setup.

What's a Mixed Network?
1. Most newer routers are dual band and broadcast a separate 2.4GHz and 5.0GHz network band. By default, they are setup to use the same Wi-Fi name and password for both. This combined dual network with the same name and password is referred to as a "Mixed Network".

My "Live View" Isn't Working When I Access The App!
1. If "Live View" is not working, leave the Energizer Connect app and go to your phone's settings. Go to the Apps settings, locate the Energizer Connect App, storage, and then clear cache.