



Solutions to Common Problems

Failed pairing:

- a. Confirm that the speaker is in search mode or restart it.
- b. If there are numerous Bluetooth devices nearby, it may be challenging to connect. Turn off other Bluetooth devices or move them away for easier pairing.

Product Usage Guidelines:

Store and operate the product at room temperature. Avoid exposing the product to rain or high humidity. Handle with care to prevent damage from dropping. Do not attempt to disassemble or repair the product yourself. The product contains a built-in lithium battery. Do not dispose of it in fire; doing so may pose a safety hazard.

Wireless Speaker



GPBT3164 Instructions



Pairing Instructions

Power On/Off: Slide the On/Off Switch to the On position.
Bluetooth Connection:

- a. To establish a Bluetooth connection, first activate Bluetooth mode on your mobile phone or other devices and search for "basically 01" for pairing. If prompted for a pairing code, enter "0000". Once paired successfully, switch to Bluetooth play mode.
- b. After successful pairing, when entering Bluetooth mode subsequently, it will automatically attempt to reconnect for 10 seconds; if no connection is established within the timeout period, it will enter pairing mode again.

Bluetooth Call:

When receiving a call, press << to answer, long press << to reject, and press << to end the call.

TF Card and U Disk:

Insert a TF card into the designated slot for automatic playback recognition. Similarly, insert a U disk for automatic playback recognition.

FM Radio:

Press the function key to switch to radio mode.

Charging:

Connect the USB plug of the charging cable to the USB charging port (DC = 5V). If using a USB-C charging head, connect it to the device. The red indicator light will illuminate to indicate charging mode and turn off once charging is complete.



FCC NOTICE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC WARNING:

To assure continued operation, follow the attached installation instructions and use only shield cables when connecting to other devices. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction